

INVERTER  
Plug-in option  
**A8NPRT\_2P**  
INSTRUCTION MANUAL

*PROFINET communication interface*

Doc.Id. HMSI-27-207  
Doc.Rev. 1.02

Art. no.: 280274  
05042019  
Version D



Version check



---

## Important User Information

This document is intended to provide a good understanding of the functionality offered by the A8NPRT\_2P PROFINET Option Board. The document only describes the features that are specific to the option board. For general information regarding the FR-A800 or FR-F800 inverter, consult the FR-A800 or FR-F800 inverter instruction manuals.

The reader of this document is expected to be familiar with high level software design, and communication systems in general. The use of advanced PROFINET-specific functionality may require in-depth knowledge in PROFINET networking internals and/or information from the official PROFINET specifications. In such cases, the people responsible for the implementation of this product should either obtain the PROFINET specification to gain sufficient knowledge or limit their implementation in such a way that this is not necessary.

### Liability

Every care has been taken in the preparation of this manual. Please inform HMS Industrial Networks AB of any inaccuracies or omissions. The data and illustrations found in this document are not binding. We, HMS Industrial Networks AB, reserve the right to modify our products in line with our policy of continuous product development. The information in this document is subject to change without notice and should not be considered as a commitment by HMS Industrial Networks AB. HMS Industrial Networks AB assumes no responsibility for any errors that may appear in this document.

There are many applications of this product. Those responsible for the use of this device must ensure that all the necessary steps have been taken to verify that the applications meet all performance and safety requirements including any applicable laws, regulations, codes, and standards.

HMS Industrial Networks AB will under no circumstances assume liability or responsibility for any problems that may arise as a result from the use of undocumented features, timing, or functional side effects found outside the documented scope of this product. The effects caused by any direct or indirect use of such aspects of the product are undefined, and may include e.g. compatibility issues and stability issues.

The examples and illustrations in this document are included solely for illustrative purposes. Because of the many variables and requirements associated with any particular implementation, HMS Industrial Networks AB cannot assume responsibility for actual use based on these examples and illustrations.

### Intellectual Property Rights

HMS Industrial Networks AB has intellectual property rights relating to technology embodied in the product described in this document. These intellectual property rights may include patents and pending patent applications in the US and other countries.

### Trademark Acknowledgements

Anybus® is a registered trademark of HMS Industrial Networks AB. All other trademarks are the property of their respective holders.

---

 **CAUTION**

- This is a class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.
- **ESD Note**  
This product contains ESD (Electrostatic Discharge) sensitive parts that may be damaged if ESD control procedures are not followed. Static control precautions are required when handling the product. Failure to observe this may cause damage to the product.

A8NPRT\_2P PROFINET Option Board Instruction Manual

Rev 1.02

Copyright© HMS Industrial Networks AB

November 2014 Doc Id HMSI-27-207

Thank you for choosing this Mitsubishi Inverter plug-in option for the Mitsubishi FR-A800 or FR-F800 Series Inverter. This Instruction Manual gives handling information and precautions for use of this equipment. Incorrect handling may cause an unexpected failure or damage. In order to ensure optimal performance, please read this manual carefully prior to use of the equipment.

Please forward this manual to the end user of the equipment.

#### **This section is specifically about safety matters**

Do not attempt to install, operate, maintain or inspect this product until you have read through this Instruction Manual and any related documents carefully, and can use the equipment correctly. Do not use this product until you have a full working knowledge of the equipment, safety information and instructions.

In this Instruction Manual, the safety instruction levels are classified into "WARNING" and "CAUTION" levels.



#### **WARNING**

Assumes that incorrect handling may cause hazardous conditions, resulting in death or severe injury.



#### **CAUTION**

Assumes that incorrect handling may cause hazardous conditions, resulting in moderate or slight injury, or may cause physical damage only.

Please note that even the **CAUTION** level may lead to a serious consequence depending on conditions. Please be sure to follow the instructions of both levels as they are critical to personnel safety.

## **SAFETY INSTRUCTIONS**

### **Electric Shock Prevention**

#### **WARNING**

- Do not open any cover on the inverter while power is on or while the inverter is running, as an electrical shock may result.
- Do not operate the inverter with any cover or wiring cover removed, as accidental contact with exposed high-voltage terminals and internal components may occur, resulting in an electrical shock.
- If power is off do not remove any cover except when necessary for wiring or periodic inspection. While any cover is removed, accidental contact with exposed high-voltage terminals and internal components may occur, resulting in an electrical shock.
- Prior to starting wiring or inspection, confirm that input power to the inverter has been switched off via observation of the inverter's display panel. Additionally, wait for at least 10 minutes after removal of input power, and then confirm that all residual voltage has been dissipated by using a voltage meter. Internal DC bus capacitors may contain high voltages for several minutes after removal of input power, resulting in a dangerous situation should anything come into contact with them.
- All personnel involved in the installation or inspection of this equipment should be fully competent to perform the required work.
- Always install plug-in options prior to wiring main power.
- Do not touch the plug-in option with wet hands.
- Do not subject the cables to scratches, excessive stress, heavy loads or pinching.

### **Injury Prevention**

#### **CAUTION**

- To prevent explosions or similar damage, apply only the voltages specified in the instruction manual to each terminal.
- To prevent explosions or similar damage, ensure that all cables are properly connected to the correct terminals.
- To prevent explosions or similar damage, observe all wiring polarity indicators.
- To prevent burns from hot components, do not touch the inverter while power is on, or for some time after power is removed.

---

## Additional Instructions

Please note the following points to prevent equipment damage, injury or electrical shock.

### Transportation and mounting

** CAUTION**

- Do not install or operate the plug-in option if it is damaged or has parts missing.
- Do not stand or rest heavy objects on the equipment.
- Check that the mounting orientation is correct.
- Prevent conductive items such as screws and metal fragments, or flammable substances such as oil from entering the inverter.

### Trial run

** CAUTION**

- To prevent unexpected equipment movement, confirm and adjust all required parameters prior to starting operation.

### Usage

** WARNING**

- Do not modify the equipment.
- Do not remove any inverter or option parts unless specifically instructed to do so in this manual.

** CAUTION**

- Performing a “parameter clear” or “all parameter clear” will reset all inverter parameters to their factory default settings. After performing one of these operations, remember to reenter any custom parameter values prior to starting operation.
- To prevent damage from electric discharge, always touch a grounded piece of metal prior to touching any equipment.

### Maintenance, inspection and parts replacement

** CAUTION**

- Do not perform hi-pot tests on the equipment.

### Disposal

** CAUTION**

- Contact the local or state environmental agency in your area for details on the disposal of electrical components and packaging.

### General instruction

For clarity purposes, illustrations in this manual may be drawn with covers or safety guards removed. Ensure all covers and safety guards are properly installed prior to starting operation.

# Table of Contents

|   |           |
|---|-----------|
| <b>About This Document .....</b>                        | <b>1</b>  |
| Related Documents .....                                 | 1         |
| Download .....  | 1         |
| Document History .....                                  | 2         |
| Conventions & Terminology .....                         | 3         |
| Support .....   | 3         |
| <br>  |           |
| <b>1. Pre-Operation Instructions.....</b>               | <b>5</b>  |
| 1.1 History .....                                       | 5         |
| 1.2 Product Overview .....                              | 5         |
| 1.3 Features.....                                       | 6         |
| 1.4 Unpacking and Product Confirmation .....            | 7         |
| 1.4.1 Shipment Confirmation.....                        | 7         |
| 1.4.2 Component Overview .....                          | 7         |
| 1.5 Environmental Specifications .....                  | 8         |
| <br>  |           |
| <b>2. Installation .....</b>                            | <b>9</b>  |
| 2.1 Pre-installation Instructions .....                 | 9         |
| 2.2 Installation Procedure .....                        | 9         |
| 2.3 Network Connector (RJ45) .....                      | 12        |
| 2.4 LED Indicators .....                                | 13        |
| <br>  |           |
| <b>3. Get Started .....</b>                             | <b>15</b> |
| 3.1 Physical Installation.....                          | 15        |
| 3.2 Download GSDML file.....                            | 15        |
| 3.3 Inverter setup .....                                | 15        |
| 3.4 Profinet Controller setup using CCPU.....           | 16        |
| 3.5 Setup of iQ-R PROFINET IO Controller Module .....   | 22        |
| 3.6 Inverter control example using Device monitor ..... | 32        |
| 3.6.1 GX Works2 assigned devices .....                  | 32        |
| 3.6.2 GX Works3 assigned devices .....                  | 32        |
| 3.6.3 Control procedure.....                            | 33        |
| 3.7 Preparing the GX Works2 Project.....                | 36        |
| 3.8 GX Works2 Telegram 1 example.....                   | 39        |
| 3.9 GX Works2 Telegram 102 example .....                | 41        |
| 3.10 GX Works2 Acyclic communication example.....       | 44        |
| 3.10.1 Reading a parameter (Sequence 1).....            | 44        |
| 3.10.2 Reading an array of parameters (Sequence 3)..... | 48        |
| 3.10.3 Changing parameters (Sequence 2).....            | 50        |
| 3.11 GX Works2 Network Detect .....                     | 53        |

|           |   |            |
|-----------|---|------------|
| 3.12      | TIA Portal Telegram 1 example .....                   | 54         |
| 3.13      | TIA Portal Telegram 102 example.....                  | 63         |
| 3.14      | TIA Portal Acyclic communication example.....         | 65         |
| 3.14.1    | Reading a parameter (Sequence 1).....                 | 65         |
| 3.14.2    | Changing parameters (Sequence 2).....                 | 72         |
| 3.15      | SIMATIC STEP7 example .....                           | 76         |
| 3.15.1    | Creating a Configuration .....                        | 76         |
| 3.15.2    | Download Configuration to the PLC.....                | 81         |
| 3.15.3    | Run .....   | 83         |
| <b>4.</b> | <b>Inverter Settings .....</b>                        | <b>85</b>  |
| 4.1       | Inverter Parameters.....                              | 85         |
| 4.2       | Option Board Parameters.....                          | 86         |
| 4.3       | Operation Mode Setting .....                          | 88         |
| <b>5.</b> | <b>Identifying the Option Board.....</b>              | <b>89</b>  |
| 5.1       | Siemens Primary Setup Tool.....                       | 89         |
| 5.2       | IP Address.....                                       | 89         |
| <b>6.</b> | <b>Embedded Web Server .....</b>                      | <b>91</b>  |
| 6.1       | Overview.....   | 91         |
| 6.2       | Authorization.....                                    | 91         |
| 6.3       | Web Pages .....                                       | 92         |
| 6.3.1     | Network Interface .....                               | 92         |
| 6.3.2     | Parameter Data.....                                   | 95         |
| 6.3.3     | Drive Monitor .....                                   | 97         |
| <b>7.</b> | <b>File System and FTP Server.....</b>                | <b>99</b>  |
| 7.1       | General.....  | 99         |
| 7.2       | FTP Server.....                                       | 99         |
| 7.2.1     | Initiation .....                                      | 99         |
| 7.2.2     | User Accounts.....                                    | 99         |
| <b>8.</b> | <b>PROFINET Implementation.....</b>                   | <b>101</b> |
| 8.1       | General.....  | 101        |
| 8.2       | Electronic Data Sheet (GSD).....                      | 101        |
| 8.3       | Fast Start Up.....                                    | 101        |
| 8.4       | DAP .....   | 101        |
| 8.5       | I&M .....   | 102        |
| <b>9.</b> | <b>Data Exchange .....</b>                            | <b>103</b> |
| 9.1       | General Information .....                             | 103        |
| 9.2       | Inverter parameters (Acyclic Data Exchange) .....     | 104        |
| 9.3       | Monitor Data (Acyclic and Cyclic Data Exchange) ..... | 104        |

---

|            |   |            |
|------------|---|------------|
| 9.4        | Drive Profile Parameters (Acyclic Data Exchange) .....            | 108        |
| 9.4.1      | PROFIdrive Parameters .....                                       | 108        |
| 9.4.2      | Setpoint- and Actual Value (P915/P916) .....                      | 109        |
| 9.4.3      | Signal List (P923) .....  | 109        |
| 9.4.4      | Drive Reset (P972) .....  | 109        |
| 9.5        | General State Diagram .....                                       | 110        |
| 9.5.1      | Stopping the motor .....  | 110        |
| 9.6        | Process Data (Cyclic Data Exchange) .....                         | 111        |
| 9.6.1      | General .....   | 111        |
| 9.6.2      | IO Device Structure .....   | 111        |
| 9.6.3      | Signals .....   | 111        |
| 9.6.4      | Telegram Types .....  | 113        |
| 9.7        | Acyclic Data Exchange .....                                       | 115        |
| 9.7.1      | Explanation of fields used in requests .....                      | 116        |
| 9.7.2      | Data format type table .....                                      | 116        |
| 9.7.3      | Error table .....   | 117        |
| 9.7.4      | Sequence 1: Request parameter value, single .....                 | 117        |
| 9.7.5      | Sequence 1: Parameter response positive .....                     | 117        |
| 9.7.6      | Sequence 1: Parameter response negative .....                     | 118        |
| 9.7.7      | Sequence 2: Change parameter value .....                          | 118        |
| 9.7.8      | Sequence 2: Parameter response positive .....                     | 118        |
| 9.7.9      | Sequence 2: Parameter response negative .....                     | 118        |
| 9.7.10     | Sequence 3: Request parameter value, several array elements ..... | 119        |
| 9.7.11     | Sequence 3: Parameter response positive .....                     | 119        |
| 9.7.12     | Sequence 3: Parameter response negative .....                     | 119        |
| <b>10.</b> | <b>Diagnostics .....</b>  | <b>121</b> |
| <b>A.</b>  | <b>Translation of Signal Numbers .....</b>                        | <b>123</b> |
| <b>B.</b>  | <b>Troubleshooting .....</b>                                      | <b>125</b> |
| B.1        | Windows Firewall Settings .....                                   | 126        |
| <b>C.</b>  | <b>HICP (Host IP Configuration Protocol) .....</b>                | <b>127</b> |
| C.1        | General .....   | 127        |
| C.2        | Operation .....   | 127        |
| <b>D.</b>  | <b>Copyright Notices .....</b>                                    | <b>129</b> |
|            | <b>Index .....</b>  | <b>131</b> |



## About This Document

For more information, documentation etc., please visit the Mitsubishi Electric website, see section "Download" below.

## Related Documents

| Document  | Author |
|---|--------|
| Installation guideline of Mitsubishi inverter drive | ME     |
| Instruction manual of Mitsubishi inverter drive     | ME     |

## Download

The following websites are available for downloads:

| Website   | Region |
|---|--------|
| <a href="https://eu3a.mitsubishielectric.com">https://eu3a.mitsubishielectric.com</a>   | EU     |
| GSDML File suitable for A800 and F800:<br><a href="https://eu3a.mitsubishielectric.com/fa/en/mymitsubishi/download_manager?id=10169">https://eu3a.mitsubishielectric.com/fa/en/mymitsubishi/download_manager?id=10169</a> (MyMitsubishi Login required) | EU     |
| GX Configurator-PN 1.03:<br><a href="https://eu3a.mitsubishielectric.com/fa/en/mymitsubishi/download_manager?id=10069">https://eu3a.mitsubishielectric.com/fa/en/mymitsubishi/download_manager?id=10069</a> (MyMitsubishi Login required)               | EU     |
| Profinet A800 function blocks:<br><a href="https://eu3a.mitsubishielectric.com/fa/en/mymitsubishi/download_manager?id=10173">https://eu3a.mitsubishielectric.com/fa/en/mymitsubishi/download_manager?id=10173</a> (MyMitsubishi Login required)         | EU     |

## Document History

### Summary of Recent Changes ( ... 1.02)

| Change  | Page(s)                                  |
|---|--|
| Various changes in screenshots and descriptions | 7, 20, 27,41, 43, 44, 49, 50, 62, 83, 85 |
| New telegram type 103                           | 98                                       |
| Setup of iQ-R PROFINET IO controller module     | 22                                       |
| New monitor data                                | 104                                      |
|   |  |
|   |  |
|   |  |
|   |  |
|   |  |
|   |  |

### Revision List

| Revision | Date    | Author(s) | Chapter(s) | Description |
|----------|---------|-----------|------------|-------------|
| 1.00     | 03/2014 |           |            |             |
| 1.01     | 01/2015 |           |            |             |
| 1.02     | 04/2019 |           |            |             |
|          |         |           |            |             |
|          |         |           |            |             |
|          |         |           |            |             |
|          |         |           |            |             |
|          |         |           |            |             |

## Conventions & Terminology

The following conventions are used throughout this manual:

- Numbered lists provide sequential steps
- Bulleted lists provide information, not procedural steps
- The term 'module' refers to the option board.
- Hexadecimal values are written in the format NNNNh, where NNNN is the hexadecimal value.

## Support

mitsubishi electric europe  
europa b.v.  
german branch  
mitsubishi-electric-platz 1  
d-40882 ratingen  
phone: +49 (0) 21 02 / 486-0  
hotline: +49 2102 1805 000-765 /-766  
fax: +49 (0) 21 02 / 4 86-1 12 0  
e-mail: megfa-mail@meg.mee.com  
<https://eu3a.mitsubishielectric.com>

mitsubishi electric usa  
automation  
500 corporate woods parkway  
vernon hills, illinois 60061  
phone: +1 (0) 847 / 478 21 00  
fax: +1 (0) 847 / 478 03 27

mitsubishi electric japan  
corporation  
tokyo bldg.  
2-7-3 marunouchi chiyoda-ku  
tokyo 100-8310  
phone: +81 (0) 3 / 32 18 31 76  
fax: +81 (0) 3 / 32 18 24 22

Please refer to the drive manual for other region contact addresses.



# 1. Pre-Operation Instructions

## 1.1 History

The FR-A800 or FR-F800 series from Mitsubishi Electric (ME), are families of frequency inverters. The communication modules, option boards, enabling communication on different industrial networks, are developed and produced by HMS Industrial Networks AB, Halmstad, Sweden.

## 1.2 Product Overview

The A8NPRT\_2P PROFINET Option Board for PROFINET allows information to be transferred seamlessly between an FR-A800 or FR-F800 inverter and a PROFINET network with minimal configuration requirements. The option board installs directly onto the inverter's control board, and presents two standard 10BASE-T/100BASE-TX Ethernet ports for connection to the PROFINET network. The interface also hosts an embedded web server, which provides access to inverter information via a standard web browser for remote monitoring, configuration and control.

The option board is connected directly to the control board of the inverter and communicates to the inverter via a built-in communication port. Note that when the inverter's network communication port is used by the A8NPRT\_2P PROFINET Option Board, it is unavailable for use by any other network.

Before using the interface, please familiarize yourself with the product and be sure to thoroughly read the instructions and precautions contained in this manual. In addition, please make sure that this instruction manual is delivered to the end user of the product, and keep this instruction manual in a safe place for future reference or unit inspection.

## 1.3 Features

- Two PROFINET ports
- PROFINET IO communication
- Drive operation according to PROFIdrive V4.1
  - Supports Application class 1 functionality
- Diagnostic support
- SNMP agent
- FTP server
- Web server
- Firmware upgrade functionality<sup>1</sup>
- Supports PROFINET Fast Start Up
- 10BASE-T/100BASE-TX full duplex Ethernet interface
- Auto negotiation enabled
- RT communication
- Network loss detection

---

<sup>1</sup> Instructions are included when downloading a new firmware version.



## 1.4 Unpacking and Product Confirmation

### 1.4.1 Shipment Confirmation

Check the enclosed items. Confirm that the correct quantity of each item was received, and that no damage occurred during shipment.

### 1.4.2 Component Overview

Included in the package are the following items.

| Item               | No. of pcs |  |
|--------------------|------------|--|
| PCB board          | 1          |   |
| M3 x 6 mm screw    | 3          |   |
| Board spacer       | 2          |   |
| LED cover          | 1          |  |
| PE plate           | 1          |  |
| Installation sheet | 1          |   |

## 1.5 Environmental Specifications

| Item                  | Specification   |
|-----------------------|---|
| Operating Temperature | -10° to +50° Celsius (ambient of the drive, non-freezing)   |
| Storage Temperature   | -40° to +65° Celsius  |
| Relative Humidity     | 93% non1.02 condensing  |
| Vibration             | Max acceleration amplitude: 10 m/s <sup>2</sup> at 9 - 200 Hz<br>Max displacement amplitude: 3 mm at 2 - 9 Hz |
| Grounding             | Connected to inverter frame ground through the PE plate / isolated from inverter control power common         |
| Power Supply          | Supplied from inverter  |
| Cooling Method        | Self cooled   |
| Communication Speed   | 10/100 Mbit   |

The A8NPRT\_2P interface is lead-free / RoHS-compliant.

## 2. Installation

### 2.1 Pre-installation Instructions


|  |  |
|--|--|
|  <b>WARNING</b> |  |
|                 | To avoid damage to the inverter or plug-in option board, never install or remove a plug-in option board while the inverter's input power is on.<br>Make sure that the inverter's power is OFF. |

Physical installation of the option board is a two-step process. First, the board will be mounted onto an available option connector on the inverter's control board. Second, the board will be connected to the PROFINET network using a network cable.


**Note:** Prior to mounting the option board in the inverter, please write down the MAC address, which is found on a label on the board.

### 2.2 Installation Procedure


- ① Make sure that power is off. After switching off the power, wait for at least 10 minutes prior to proceeding with the installation.
- ② Remove both lids of the FR-A800 or FR-F800.
  - Unscrew the two screws in the bottom corners of the inverter.
  - Remove the lid covering the lower front of the inverter.
  - Unscrew the screw in the bottom right corner of the lid covering the upper front of the inverter.
  - Remove the lid.



- ③ Put the included board spacers in the holes at the right top and left bottom corners of the PCB.



- ④ Position the A8NPRT\_2P PROFINET Option Board at the option slot 1 as shown in the image. This is the only position that will allow network connectivity.




- ⑤ Fasten the option board by tightening the included screws at the top left and bottom right corners. The PE plate is attached along with the screw in the bottom right corner.

---


**Note:** Over-tightening the screws will damage the board.

---

- ⑥ Fasten the other end of the PE plate with another screw as shown in the picture.



- ⑦ Attach network cable(s) to any of the network connectors on the option board.




---


**Note:** The shield of the RJ45 connector is not connected directly to PE. As all nodes in a PROFINET network have to share chassis ground connection, the PROFINET cable shield has to be connected to the chassis ground at each node in the network. Chassis ground is available in the PE plate.

---

- ⑧ To fit the LED cover on the front cover of the drive, do as follows:
- Cut the bridges, using nippers, on the upper front cover.



- Snap the LED cover into the front cover of the drive.



- Fasten both front covers, top front cover first.

The option board is now mounted and power can be applied.


#### Removal

- Remove both lids of the FR-A800 or FR-F800.
- Remove the network cable(s).
- Remove the screws.
- Carefully remove the option board by lifting it straight up.
- Remove the board spacers.
- Replace the lids.

## 2.3 Network Connector (RJ45)

The option board provides connection to PROFINET through two identical network connectors.

| Pin     | Name   | Description                               |
|---------|--------|---|
| 1       | TX+    | Transmit positive                         |
| 2       | TX-    | Transmit negative                         |
| 3       | RX+    | Receive positive                          |
| 4       | NC     | Terminated with a 50-75 $\Omega$ resistor |
| 5       | NC     |   |
| 6       | RX-    | Receive negative                          |
| 7       | NC     | Terminated with a 50-75 $\Omega$ resistor |
| 8       | NC     |   |
| Housing | Shield | Filter connection to PE                   |



## 2.4 LED Indicators



| LED            | State                    | Status  |
|----------------|--------------------------|---|
| Network status | Off                      | Offline: no power or no connection to IO Controller                                 |
|                | Green                    | Online (RUN): connection to IO Controller established, IO controller in RUN state.  |
|                | Flashing Green           | Online (STOP): connection to IO Controller established, IO controller in STOP state |
| Module status  | Off                      | Not initialized: no power or setup not finished                                     |
|                | Green                    | Operational   |
|                | Green, 1 flash           | Diagnostic event(s) present   |
|                | Green, 2 flashes         | Used by engineering tools to identify the node on the network                       |
|                | Red                      | Exception error: the option board is in the exception state.                        |
|                | Red, 1 flash             | Configuration error: expected identification differs from real identification.      |
|                | Red, 2 flashes           | IP Address Error: IP address not set.   |
|                | Red, 3 flashes           | Station Name not set.   |
| Link (1, 2)    | Off                      | No link: no communication present   |
|                | Green                    | Link: Ethernet link established, no communication present                           |
|                | Flickering               | Activity: Ethernet link established, communication present                          |
| Error          | Off                      | Communication with inverter is working without problems.                            |
|                | Red                      | Error in communication with inverter  |
|                | Red, flashing (2 blinks) | Invalid process data parameter mapped   |
|                | Red, flashing (3 blinks) | Too many process data parameters mapped   |



## 3. Get Started

All example programs described in this chapter are available for download from the MyMitsubishi website, see section "Download" on page 1 for a direct link.

### 3.1 Physical Installation

It is recommended to make a note of the MAC address of the option board, prior to installing the module in the inverter. The MAC address can for example be found on the label located on the option board.

The physical installation of the option board is described in "Installation Procedure" on page 9.

### 3.2 Download GSDML file

Download the appropriate GSDML file from the Mitsubishi Electric website, see section "Download" on page 1 for a direct link.

### 3.3 Inverter setup

This chapter describes the first part of setting up a system using an A800 or F800 inverter controlled by Profinet. It assumes that the A8NPRT-2P option card has been installed correctly, and all inverter parameters are set to default values. This setup will be used for all get started example programs.

Set parameters 1305 – 1308 as the IP Address of the option board. For this tutorial use address 192.168.3.17 which corresponds to the following settings:

| Parameter No. | Value |
|---------------|-------|
| 1305          | 192   |
| 1306          | 168   |
| 1307          | 3     |
| 1308          | 17    |

Similarly, set parameters 1309-1312 as the subnet mask 255.255.255.0:

| Parameter No. | Value |
|---------------|-------|
| 1309          | 255   |
| 1310          | 255   |
| 1311          | 255   |
| 1312          | 0     |

Set parameter 1317 to "3" in order to read the settings from the option board parameters.


| Parameter No. | Value |
|---------------|-------|
| 1317          | 3     |

The final step is to change the operation mode of the inverter to network. One way to do this is by leaving the default setting of parameter 79 (0), and setting parameter 340 to 1. After restarting the inverter, it should operate in network mode. For detailed settings, please refer to A800 or F800 manual.

### 3.4 Profinet Controller setup using CCPU

This chapter describes setting up a Profinet controller using Q12DCCPU-V for use with the A8NPRT\_2P Profinet option card.

For this setup use a Q series PLC with high speed data transfer enabled and a C CPU (Profinet Controller) in a multi CPU setup.




Connect the PC, C-controller and PROFINET option card to the same network using a switch. (switch is needed because both C-Controller and Profinet option must be available during hardware configuration)

Make sure that PC's IP is set to match to the IP set of the option board – both need to be in the same subnetwork.


Network 192.168.3.xxx is recommended since 192.168.3.3 is the default IP address of the Mitsubishi C-controller.

Run GX Configurator PN 1.03 or newer to setup the Profinet controller. Select the Ethernet adapter used by the PC, and click *Detect* to search for the Profinet controller.




If the controller is not found, check the Ethernet adapter settings to match the settings of the Profinet controller. The default address of the Profinet controller is 192.168.3.3, if the address was changed, and the set address is not recalled, refer to the Profinet controller manual on how to reset to factory settings.


Once the controller is detected, select the controller, and click on the arrows to copy the controller settings.




Finally click on OK to accept the settings.




To add the A8NPRT\_2P Profinet option card to the device library, right click on the device library, and click add.




Follow the instructions on screen to add the GSDML File supplied with the A8NPRT\_2P Profinet option card. If this is done successfully, the device library should look like on the screenshot below.




Click on the *Network Detection* tab, then right click on the Network node and select *Online action*.




A search of available network devices is performed. Once the A8NPRP-2P Option card is found (look at the *type* column), it is ok to turn off scanning. Apply a Profinet Device Name for the inverter (be sure to check the *Permanent Name* checkbox) and click *Apply Name*. After a successful name change, it is ok to close this window. At this point the option card's Module Status LED should be solid green.



In the *Network Detection* tab right click and select *Read Network Configuration* from the context menu. A prompt asking to accept the PLC settings may be shown; accept the current settings, as they will be changed later on. This will add all Profinet devices to the network tree. Drag the option card to the configuration window.




The device parameters will be added to the configuration. Click on the *Module Configuration* tab, and add the *Telegram 1 (PROFdrive)* telegram to the configured module tab.




Download the setup to the controller by clicking on *File -> Download configuration*. As a result a message in the *Output message view* at the bottom of the window should be shown.

Enter *File -> PLC Settings* to create the necessary parameter updates. Click on *Configure* to setup the *Multiple CPU Settings*. In the QCPU setup, click on the *PLC Project* entry to modify the path to the PLC project. If the PLC project is not yet created, then do this now. The project must be saved with a GX Works 2 1.502 version or newer. After entering this path, click on *OK* to close the *Multiple CPU settings* window.



The output and input devices in the PLC Settings can be changed as needed. Make sure none of these devices overlap with devices used in the project. Click on *Update* to update the *Actual CPU List*. To create a connection with the Q PLC, click on *Transfer Setup* and follow the instructions on screen. Now click on *Update parameters...* to update parameters on the QCPU, Profinet Controller and GX Works 2 project. When prompted whether to perform an offline or online and offline update, pick the later.



After all three updates finish successfully, the setup of the Profinet controller is complete.

## 3.5 Setup of iQ-R PROFINET IO Controller Module

This chapter describes step by step the configuration of the PROFINET IO controller module RJ71PN92 in combination with the A/F800 Profinet option card A8NPRT\_2P.


To configure the hardware following software is needed:

- GX Configurator-PN version 2.00 or later.


Connect the A8NPRT\_2P option card and RJ71PN92 module to the same network using a switch. Connect the IQ-R CPU to PC either by USB or Ethernet cable.

Assuming that the Module Configuration was already downloaded to the PLC, please do following additional steps to configure a new Profinet slave:

From Navigation tree select *Project -> Module Configuration*. Then select *Online -> Read Module Configuration from PLC*.




Module configuration data will be read from PLC and the project will be updated.




Close *Module Configuration* tab and agree to fix parameter.


From navigation tree select *Parameter -> Module Information -> 0000:RJ71PN92 -> Module Parameter*.



In the *Module Configuration* tab under *Basic Settings* set the controller *IP address* and *subnet mask*. Make sure that the controller and A8NPRT use the same subnetwork.




Then set controller name.






Close the *Module Configuration* tab and save project.

To open GX configurator-PN from navigation tree select *Parameter -> Module Information -> 0000:RJ71PN92 -> PROFINET Module Setting*.




If A8NPRT\_2P GSDML file is not already in the device library it needs to be added. Right click *Device Library* and select *Add*.






To set the device name, make a right click on *Network* and select *Online Action*.




After the device is found on network deselect *Scanning* and name the device.




If the Online Action doesn't detect the Profinet option and end up with a time out, please refer to Appendix B.1 "Windows Firewall Settings".


Next right click on *Network* and select *Read Network Configuration*.



After the device was found select *Insert in Configuration* and confirm with the *Okay* button.




When the device is inserted it can be configured. Make a double click on *Module Configuration* and select the needed Telegram. Telegram 1 is already set as default.





After the device was added to the configuration save the modifications and exit the GX Configurator-PN.

In GX Works3 project select from navigation tree *Parameter -> Module Information -> 0000:RJ71PN92* and select *Autorefresh Settings* to see input and output devices.




Following devices were assigned to PROFINET input and output data.



To see complete list of I/O mapping select Show I/O mapping.  
Click on OK and agree to update data structures and global label.

Use the Convert function to built the GX Works project. Save the project and write the Parameter + Program down to the PLC.



After data was written reset the PLC and wait for PROFINET module to boot (RUN and PN RUN LEDs are ON). This ends PROFINET master configuration.

## 3.6 Inverter control example using Device monitor

This chapter describes step by step how to control inverter with using Device/Buffer Memory Batch Monitor in GX Works2 and GX Works3. Control sequence is not specific to those two programs and could be used on any master. Telegram 1 – speed control is used for this example.

### 3.6.1 GX Works2 assigned devices

This example assumes that setup guide from chapter 3.4 has been followed.

With standard setup PROFINET signals are assigned to following devices:

| Signal                      | Device |
|-----------------------------|--------|
| PROFINET management input   | X100   |
| PROFINET management output  | Y100   |
| Controlword (STW1)          | D4543  |
| Speed setpoint (NSOLL_A)    | D4544  |
| Statusword (ZSW1)           | D4547  |
| Speed actual value (NIST_A) | D4548  |

### 3.6.2 GX Works3 assigned devices


This example assumes that setup guide from chapter 3.5 has been followed.

With standard setup PROFINET signals are assigned to following devices:


| Signal                      | Device |
|-----------------------------|--------|
| PROFINET management input   | D58    |
| PROFINET management output  | D0     |
| Controlword (STW1)          | D109   |
| Speed setpoint (NSOLL_A)    | D110   |
| Statusword (ZSW1)           | D111   |
| Speed actual value (NIST_A) | D112   |

### 3.6.3 Control procedure

The PLC program has to set the bits in control word 1 (STW1) accordingly in order to get through the Profidrive state machine. S4: Operation.




To open Device/Buffer Memory Batch Monitor in GX Works select *Online -> Monitor -> Device/Buffer Memory Batch Monitor*.




Following example uses device numbers from GX Works3. Same thing applies to GX Works2, but device addresses are as in section 3.6.1.


- ① To start data exchange set bit 0 (DataExchangeStart bit) of PROFINET management output to ON.



- ② Bit 3 of PROFINET management input should change to ON, data exchange start was completed.



- ③ Set bit 10 of Controlword to ON (control by PLC), bits 6 and 9 of Statusword should turn ON (control requested and switch on inhibited).



- ④ Set bits 1 and 2 of Controlword to ON (no quick stop, no coast stop), bit 6 of Statusword should change to OFF, bits 0, 4 and 5 should turn ON (ready to switch ON, coast stop not activated, quick stop not activated).

The screenshot shows the Device Monitor interface for device D109. The Controlword (D109) has bits 1 and 2 set to 1. The Statusword (D111) has bits 0, 4, and 5 set to 1, and bit 6 set to 0.

| Device Name | F | E | D | C | B | A | 9 | 8 | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 | Current Value | String  |
|-------------|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---------------|---------|
| D109        | 0 | 0 | 0 | 0 | 0 | 1 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 1 | 1 | 0 | Controlword   | 1030 .. |
| D110        | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |               | 0 ..    |
| D111        | 0 | 0 | 0 | 0 | 0 | 0 | 1 | 0 | 0 | 0 | 1 | 1 | 0 | 0 | 0 | 1 | Statusword    | 561 1.  |
| D112        | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |               | 0 ..    |

- ⑤ Set bit 0 of Controlword to ON (ON), bit 1 of Statusword should turn ON (ready to switch on).

The screenshot shows the Device Monitor interface for device D109. The Controlword (D109) has bits 0, 1, and 2 set to 1. The Statusword (D111) has bit 1 set to 1.

| Device Name | F | E | D | C | B | A | 9 | 8 | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 | Current Value | String  |
|-------------|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---------------|---------|
| D109        | 0 | 0 | 0 | 0 | 0 | 1 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 1 | 1 | 1 | Controlword   | 1031 .. |
| D110        | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |               | 0 ..    |
| D111        | 0 | 0 | 0 | 0 | 0 | 0 | 1 | 0 | 0 | 0 | 1 | 1 | 0 | 0 | 1 | 1 | Statusword    | 563 3.  |
| D112        | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |               | 0 ..    |

- ⑥ Set Speed setpoint value.

The screenshot shows the Device Monitor interface for device D109. The Controlword (D109) has bits 0, 1, 2, and 3 set to 1. The Speed setpoint (D110) is 3113. The Statusword (D111) has bits 0, 1, 2, 3, 4, and 5 set to 1.

| Device Name | F | E | D | C | B | A | 9 | 8 | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 | Current Value  | String  |
|-------------|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|----------------|---------|
| D109        | 0 | 0 | 0 | 0 | 0 | 1 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 1 | 1 | 1 | Controlword    | 1031 .. |
| D110        | 0 | 0 | 0 | 0 | 1 | 1 | 0 | 0 | 0 | 0 | 1 | 0 | 1 | 0 | 0 | 1 | Speed setpoint | 3113 ). |
| D111        | 0 | 0 | 0 | 0 | 0 | 0 | 1 | 0 | 0 | 0 | 1 | 1 | 0 | 0 | 1 | 1 | Statusword     | 563 3.  |
| D112        | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |                | 0 ..    |

- ⑦ Set bit 3 of Controlword to ON (enable operation), bits 2 and 15 of Statusword should turn ON (operation enabled, pulses enabled). Drive now rotates, Actual speed value is updated.

The screenshot shows the Device Monitor interface for device D109. The Controlword (D109) has bits 0, 1, 2, and 3 set to 1. The Speed setpoint (D110) is 3113. The Statusword (D111) has bits 2 and 15 set to 1. The Speed actual value (D112) is 3133.


| Device Name | F | E | D | C | B | A | 9 | 8 | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 | Current Value      | String    |
|-------------|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|--------------------|-----------|
| D109        | 0 | 0 | 0 | 0 | 0 | 1 | 0 | 0 | 0 | 0 | 0 | 0 | 1 | 1 | 1 | 1 | Controlword        | 1039 ..   |
| D110        | 0 | 0 | 0 | 0 | 1 | 1 | 0 | 0 | 0 | 0 | 1 | 0 | 1 | 0 | 0 | 1 | Speed setpoint     | 3113 ).   |
| D111        | 1 | 0 | 0 | 0 | 0 | 0 | 1 | 1 | 0 | 0 | 1 | 1 | 0 | 1 | 1 | 1 | Statusword         | -31945 7. |
| D112        | 0 | 0 | 0 | 0 | 1 | 1 | 0 | 0 | 0 | 0 | 1 | 1 | 1 | 1 | 0 | 1 | Speed actual value | 3133 =.   |

To change drive speed set different value to speed setpoint.


Turning OFF bits 1 or 3 of Controlword will result in drive coasting to stop. Turning OFF bits 0 or 2 of Controlword will result in drive stopping with a ramp. For details refer to the General State Diagram at the beginning of this section.

### 3.7 Preparing the GX Works2 Project


Open the PLC project updated by GX Configurator PN. If the update was successful, the *I/O Assignment* and *Multiple CPU Setting* tabs of the *PLC Parameter* should be setup.



A new library should also be available in the *User library* tab. Click on the lock pad icon to unlock access to the user library.





Enter the global label definition file and modify the label names to your liking. The labels must also be modified in the function blocks supplied in this library. The recommended way to do this is to select *Find/Replace => Replace String* from the top menu. Click on *Browse* to select the locations to search for string occurrences. Be sure to select the imported user library. Click on *OK* to return to the previous window. In the *Find String* field enter the current variable name, and in *Replace String* enter the new variable name. Finally click on *All Replace* to replace all occurrences in the user library. Repeat this process for each variable.




For easier following of the tutorial, it is recommended to follow the naming as on the screenshot below.

|    | Class      | Label Name           | Data Type                    |
|----|------------|----------------------|------------------------------|
| 1  | VAR_GLOBAL | a800In               | tSLV17SLOT1_IN               |
| 2  | VAR_GLOBAL | A800Out              | tSLV17SLOT1_OUT              |
| 3  | VAR_GLOBAL | ProfinetOut          | tPN_MGMT_OUTPUTS             |
| 4  | VAR_GLOBAL | ProfinetIn           | tPN_MGMT_INPUS               |
| 5  | VAR_GLOBAL | AcyclicReq1          | tPN_ACYCLIC_REQ              |
| 6  | VAR_GLOBAL | AcyclicReq2          | tPN_ACYCLIC_REQ              |
| 7  | VAR_GLOBAL | AcyclicRes1          | tPN_ACYCLIC_RES              |
| 8  | VAR_GLOBAL | AcyclicRes2          | tPN_ACYCLIC_RES              |
| 9  | VAR_GLOBAL | AcyclicDiag          | tPN_ACYCLIC_DIAG_INPUS       |
| 10 | VAR_GLOBAL | CyclicOut            | tPN_CYCLIC_OUTPUTS           |
| 11 | VAR_GLOBAL | CyclicIn             | tPN_CYCLIC_INPUS             |
| 12 | VAR_GLOBAL | ProfinetDetect       | tPN_DEVICE_DETECT_DATA(1..1) |
| 13 | VAR_GLOBAL | requestProfinetStart | Bit                          |
| 14 |            |                      |                              |

Do the same for structured data types *tSLV17SLOT1\_IN* and *tSLV17SLOT1\_OUT*.




Return to the project tab, and delete the *MAIN* program file from the *Program Setting*, and move the *MAIN1* program file to *Scan Program*. Expand the tree node, and edit the *Init* program. In this ladder program include the initialization procedure for Profinet communication. The ladder program includes auto initialization during PLC startup, as well as on-demand initialization.



The base program that will be used for all examples is now ready.

### 3.8 GX Works2 Telegram 1 example

- ① Start with the project created in the Preparing the GX Works2 Project chapter. After powering up the inverter and Profinet controller, connection will be established. Expect to see bit 6 (Switching on inhibited) set in ZSW1. Below is a simplified state diagram, dependent on control word 1 (STW1).




Control Word 1 (STW1) description

| State / Bit combination | Bit 10         | Bit 7             | Bit 3            | Bit 2         | Bit 1         | Bit 0 |
|-------------------------|----------------|-------------------|------------------|---------------|---------------|-------|
| Description             | Control By PLC | Fault acknowledge | Enable operation | No quick stop | No coast stop | On    |
| Switching On Inhibited  | -              | -                 | -                | -             | 0             | -     |
|                         | -              | -                 | -                | 0             | -             | -     |
| Ready To Switch On      | -              | -                 | -                | 1             | 1             | -     |
| Switched On             | -              | -                 | -                | 1             | 1             | 1     |
| Operation               | -              | -                 | 1                | 1             | 1             | 1     |
| Rotation                | 1              | -                 | 1                | 1             | 1             | 1     |
| Fault reset             | -              | 0 => 1            | -                | -             | -             | -     |

- ② It is needed to set both No Coast Stop and No Quick Stop to reset the Switching On Inhibited bit in ZSW1. To do this set bits 1 and 2 in STW1, that is global label *a800Out.STW1*.


Input the following ladder block to allow the inverter to enter “Ready For Switching On” status, after connection is established, and initialization command is given (M0).




- ③ This initialization will result in setting bit 0 in ZSW1 (Ready To Switch On). The next step is to switch on the inverter, and start operation. To do this enable bits 0 (ON/Off), 3 (enable operation), and 10 (Control By PLC) of STW1; while leaving bits 1 and 2 enabled.

In the same ladder block, set the desired rotation frequency. Assuming the motor is rated for 50 Hz (inverter parameter 3) and a frequency of 10 Hz is the target run frequency (20% of the rated motor speed). The value in Profidrive to allow full power is 16384, so in order to set 20% of the rated motor speed as the run frequency, set value 3277 to the NSOLL\_A output (3276,8 round to 3277).

Add the following ladder block to enable rotation command after initialization, and giving rotation command (M1).



- ④ Finally add the code to stop the drive, when M1 is reset. In a new ladder block, check whether the first 3 bits of ZSW1 are ON. This condition means that the drive is in operation mode. If this condition is met, and M1 is not ON, reset the set point speed to zero, and set STW1 as 6.




- ⑤ Compile, and write the program and parameters to the PLC. After resetting the PLC, and powering up the inverter, turning on bits M0 and M1 will result in running the inverter with a frequency of 10 Hz.


### 3.9 GX Works2 Telegram 102 example

This example builds upon the GX Works2 Telegram 1 module.

- ① To use Telegram 102, return to GX Configurator PN and update the configuration. Open the previous configuration and double click on the A800 Inverter Profinet device to bring up the configuration window. Click on the *Module Configuration* tab, and select *Telegram 1 (PROFdrive)*. Now click on the red cross to delete this module.




- ② Drag *Telegram 102 (Custom)* from the *Available modules* section to the *Configured modules* section. Now double click on the module to bring up the *Module Configuration* window.



- ③ The setup of the telegram is done by entering signal/parameter numbers into the right column. It is possible to view all monitor data as input, and some of the profile parameters as input/output. Please keep in mind, that not all parameters can be accessed via cyclic communication. The PROFIdrive parameter numbers (PNUs) available for use are listed in the Data Exchange subchapters 9.1 to 9.4. An example setup is provided below:

| Slot         | Description            | PNU   |
|--------------|------------------------|-------|
| Output PZD/2 | Speed set point        | 14317 |
| Input PZD/2  | Actual speed set point | 14319 |
| Input PZD/3  | Output frequency       | 9193  |
| Input PZD/4  | Output voltage         | 9195  |
| Input PZD/5  | Actual operation time  | 9215  |



- ④ Finally download the configuration to the device, and update the parameters on the PLC, Profinet controller, and GX Works 2 project. Edit the global labels in the new library to your needs (as shown in chapter Preparing the GX Works2 Project). Change the names of structured data types `tSLV17SLOT1_IN` and `tSLV17SLOT1_OUT`:

|    | Label Name     | Data Type                         |
|----|----------------|-----------------------------------|
| 1  | ZSW1           | Word[Unsigned]/Bit String[16-bit] |
| 2  | NIST_A         | Word[Unsigned]/Bit String[16-bit] |
| 3  | OutputFreq     | Word[Unsigned]/Bit String[16-bit] |
| 4  | OutputVolt     | Word[Unsigned]/Bit String[16-bit] |
| 5  | OpTime         | Word[Unsigned]/Bit String[16-bit] |
| 6  | SLOT001_INPUTG | Word[Unsigned]/Bit String[16-bit] |
| 7  | SLOT001_INPUTH | Word[Unsigned]/Bit String[16-bit] |
| 8  | SLOT001_INPUTI | Word[Unsigned]/Bit String[16-bit] |
| 9  | SLOT001_INPUTJ | Word[Unsigned]/Bit String[16-bit] |
| 10 | SLOT001_INPUTK | Word[Unsigned]/Bit String[16-bit] |
| 11 | SLOT001_INPUTL | Word[Unsigned]/Bit String[16-bit] |
| 12 | SLOT001_INPUTM | Word[Unsigned]/Bit String[16-bit] |
| 13 | SLOT001_INPUTN | Word[Unsigned]/Bit String[16-bit] |
| 14 | SLOT001_INPUTO | Word[Unsigned]/Bit String[16-bit] |
| 15 | SLOT001_INPUTP | Word[Unsigned]/Bit String[16-bit] |
| 16 | SLOT001_INPUTQ | Word[Unsigned]/Bit String[16-bit] |
| 17 | SLOT001_INPUTR | Word[Unsigned]/Bit String[16-bit] |
| 18 | SLOT001_INPUTS | Word[Unsigned]/Bit String[16-bit] |
| 19 | SLOT001_INPUTT | Word[Unsigned]/Bit String[16-bit] |
| 20 | SLOT001_INPUTU | Word[Unsigned]/Bit String[16-bit] |
| 21 |                |                                   |
| 22 |                |                                   |
| 23 |                |                                   |
| 24 |                |                                   |
| 25 |                |                                   |
| 26 |                |                                   |
| 27 |                |                                   |
| 28 |                |                                   |
| 29 |                |                                   |

|    | Label Name      | Data Type                         |
|----|-----------------|-----------------------------------|
| 1  | STW1            | Word[Unsigned]/Bit String[16-bit] |
| 2  | NSOLL_A         | Word[Unsigned]/Bit String[16-bit] |
| 3  | SLOT001_OUTPUTD | Word[Unsigned]/Bit String[16-bit] |
| 4  | SLOT001_OUTPUTE | Word[Unsigned]/Bit String[16-bit] |
| 5  | SLOT001_OUTPUTF | Word[Unsigned]/Bit String[16-bit] |
| 6  | SLOT001_OUTPUTG | Word[Unsigned]/Bit String[16-bit] |
| 7  | SLOT001_OUTPUTH | Word[Unsigned]/Bit String[16-bit] |
| 8  | SLOT001_OUTPUTI | Word[Unsigned]/Bit String[16-bit] |
| 9  | SLOT001_OUTPUTJ | Word[Unsigned]/Bit String[16-bit] |
| 10 | SLOT001_OUTPUTK | Word[Unsigned]/Bit String[16-bit] |
| 11 | SLOT001_OUTPUTL | Word[Unsigned]/Bit String[16-bit] |
| 12 | SLOT001_OUTPUTM | Word[Unsigned]/Bit String[16-bit] |
| 13 | SLOT001_OUTPUTN | Word[Unsigned]/Bit String[16-bit] |
| 14 | SLOT001_OUTPUTO | Word[Unsigned]/Bit String[16-bit] |
| 15 | SLOT001_OUTPUTP | Word[Unsigned]/Bit String[16-bit] |
| 16 | SLOT001_OUTPUTQ | Word[Unsigned]/Bit String[16-bit] |
| 17 | SLOT001_OUTPUTR | Word[Unsigned]/Bit String[16-bit] |
| 18 | SLOT001_OUTPUTS | Word[Unsigned]/Bit String[16-bit] |
| 19 | SLOT001_OUTPUTT | Word[Unsigned]/Bit String[16-bit] |
| 20 | SLOT001_OUTPUTU | Word[Unsigned]/Bit String[16-bit] |
| 21 |                 |                                   |
| 22 |                 |                                   |
| 23 |                 |                                   |
| 24 |                 |                                   |
| 25 |                 |                                   |
| 26 |                 |                                   |
| 27 |                 |                                   |
| 28 |                 |                                   |
| 29 |                 |                                   |

The PLC program for telegram 102 is the same as for telegram 1. The library programs will have been overwritten, so it is needed to write them again, or import them from the old telegram 1 project. After this, write the program and parameters to the PLC. Start the inverter in the same way as with telegram 1. Below is a screenshot that shows the input/output variables in the process of speeding up to the set frequency.

| Device/Label   | Current Value | Data Type                         | Class       | Device | Address   | Comment |
|----------------|---------------|-----------------------------------|-------------|--------|-----------|---------|
| M0             | 1             | Bit                               |             | M0     | %MX0.0    |         |
| M1             | 1             | Bit                               |             | M1     | %MX0.1    |         |
| a800OutSTW1    | 1039          | Word[Unsigned]/Bit String[16-bit] |             | D4543  | %MW0.4543 |         |
| a800OutNSOLL_A | 3277          | Word[Unsigned]/Bit String[16-bit] |             | D4544  | %MW0.4544 |         |
| a800In         |               | Word[Unsigned]/Bit String[16-bit] | VAR_GLOB... |        |           |         |
| ZSW1           | 33335         | Word[Unsigned]/Bit String[16-bit] |             | D4565  | %MW0.4565 |         |
| NIST_A         | 1321          | Word[Unsigned]/Bit String[16-bit] |             | D4566  | %MW0.4566 |         |
| OutFreq        | 404           | Word[Unsigned]/Bit String[16-bit] |             | D4567  | %MW0.4567 |         |
| OutVolt        | 0             | Word[Unsigned]/Bit String[16-bit] |             | D4568  | %MW0.4568 |         |
| OpTime         | 11            | Word[Unsigned]/Bit String[16-bit] |             | D4569  | %MW0.4569 |         |
| SLOTO01_INPUTE | 0             | Word[Unsigned]/Bit String[16-bit] |             | D4570  | %MW0.4570 |         |
| SLOTO01_INPUTE | 0             | Word[Unsigned]/Bit String[16-bit] |             | D4571  | %MW0.4571 |         |

## 3.10 GX Works2 Acyclic communication example

This chapter describes using acyclic communication with the A8NPRT-2 Profinet option card using GX Works 2 with a QCPU and Q12DCCPU-V Profinet controller. It contains examples of reading and writing individual parameters, as well as arrays. First perform the inverter setup, and prepare the GX Works project according to chapter Profinet Controller setup using CCPU.

The process of acyclic communication parameter read consists of a write request, and a response read. For details please refer to the Acyclic Data Exchange subchapter 9.7. These operations are done using function blocks generated by GX Configurator PN. Although it is possible to perform acyclic communication without this library, it exceeds the scope of this manual.

### 3.10.1 Reading a parameter (Sequence 1)


#### Creating the request

Start by preparing the content for the parameter read request. The data request has the following format:

| Byte no. | Description       | Value                  |
|----------|-------------------|------------------------|
| 0        | Request ID        | 0x01                   |
| 1        | Request reference | 0x01-0xFF              |
| 2        | No. of parameters | 0x01                   |
| 3        | DO-ID             | 0x01                   |
| 4        | No. of elements   | 0x00                   |
| 5        | Attribute value   | 0x10 (value attribute) |
| 6-7      | Parameter number  | Byte swapped PNU       |

Request reference is any valid number, this value is mirrored back in the response and can be used to distinguish multiple requests. The parameter number needs to be byte swapped (the SWAP instruction can be used to swap the lower and higher byte of a word).

In the code below *requestParameterNo* contains the unswapped parameter number, while *requestParameterNoBS* contains the byte swapped version. The content of the parameter request (*DataToWrite*), and the function block that executes the request (*Write\_Rec\_Ex*), are shown on the screenshot below:




Below is an explanation of the inputs of the function block for this use case:

| Write_Rec_Ex input description |       |                                       |                |
|--------------------------------|-------|---------------------------------------|----------------|
| Variable                       | Type  | Description                           | Value          |
| REQ                            | Bool  | Start write record                    | FALSE/TRUE     |
| BUFFER_2                       | Bool  | Set to TRUE to use Buffer2            | FALSE          |
| ID                             | DWord | Last octet of the device's IP address | 17             |
| API                            | DWord | API number                            | 0x3a00         |
| SLOTNUMBER                     | Word  | Slot number target                    | 1              |
| SUBSLOTNUMBER                  | Word  | Sub-slot number target                | 1              |
| INDEX                          | Word  | Index of the record block             | 47             |
| RECORD                         | Word  | First element of write data           | DataToWrite[0] |
| LENGTH                         | Int   | Write data size in byte               | 16             |

### Receiving the response

If the request is completed successfully (bit *delayRead* is ON), perform a response read after a delay of 500ms. Due to the nature of Profidrive acyclic communication, the response may not be immediately available after execution of the request. Waiting a small amount of time significantly increases the chance of receiving a response on the first try. Another solution is to keep executing read requests, until a proper read request is received.

It should also be noted, that 240 bytes can always be read. This is the maximum allowed length of a response. In case of a shorter response, only the available data will be read. The inputs for function block *Read\_Rec\_Ex* are similar to those of *Write\_Rec\_Ex*. The response data is available on output *RECORD*. The first element of the array that should hold the response should be connected to this output.




If the response is received successfully (bit *validRead* is ON), then it is possible to access the received data from *readData*. The format of a positive response is as follows:

| Byte no. | Description       | Value                          |
|----------|-------------------|--------------------------------|
| 0        | Request ID        | 0x01                           |
| 1        | Request reference | 0x01-0xFF (same as in request) |
| 2        | No. of parameters | 0x01                           |
| 3        | DO-ID             | 0x01                           |
| 4        | No. of values     | 0x01                           |
| 5        | Format            | See data format type table     |
| 6-7      | Parameter value   | Byte swapped parameter value   |

In case of a negative response, the format is as follows:

| Byte no. | Description       | Value                                      |
|----------|-------------------|--|
| 0        | Request ID        | 0x81                                       |
| 1        | Request reference | 0x01-0xFF (same as in request)             |
| 2        | No. of parameters | 0x01                                       |
| 3        | DO-ID             | 0x01                                       |
| 4        | No. of values     | 0x01                                       |
| 5        | Format            | 0x44 (error)                               |
| 6-7      | Error value       | Byte swapped error value (see error table) |

The request ID can be checked to distinguish a positive/negative response. Extract the parameter/error value from *readData*, and byte swap it to receive the actual value:



### Executing example requests

After compiling the program, and writing it to the PLC, try a parameter read request. The PROFIdrive parameter numbers (PNUs) available for use are listed in the Data Exchange subchapters 9.1 to 9.4. First, get the inverter running by setting bits M0 and M1. Then read the actual frequency by writing PNU 9193 to *requestParameterNo* and setting bit *requestParameter*. The result should be a value of 1000 in *parameterValue* which corresponds to 10Hz.


| Device/Label                       | Current Value | Data Type                         |
|------------------------------------|---------------|-----------------------------------|
| M0                                 | 1             | Bit                               |
| M1                                 | 1             | Bit                               |
| PROFINETASCII/requestParameter     | 0             | Bit                               |
| PROFINETASCII/requestParameterNo   | 9193          | Word[Unsigned]/Bit String[16-bit] |
| PROFINETASCII/parameterReadSuccess | 1             | Bit                               |
| PROFINETASCII/parameterReadError   | 0             | Bit                               |
| PROFINETASCII/parameterValue       | 1000          | Word[Unsigned]/Bit String[16-bit] |

### 3.10.2 Reading an array of parameters (Sequence 3)

Certain parameters are available in the form of an array. It is possible to access individual elements of the array by changing the subindex. It is also possible to retrieve multiple elements of the array by executing sequence 3. This requires only changing byte no. 4 of the request (No. of values) to the amount of array values wanted. The response will contain additional parameter values added to the end of the response data.


#### Creating the request

For this example all 5 array elements of PNU 964 (Device identification) will be requested. Modify the parameter request as shown below:



### Reading the response

Modify the code reading the response data, to read all 5 elements, and byte swap each one. An example procedure how to do this is shown below. The byte-swapped elements will be available in the array *parameterValue*.



### Executing example request

After executing a request, the response data is available in the *parameterValue* variable.

| Device/Label                       | Current Value | Data Type                             |
|------------------------------------|---------------|---------------------------------------|
| M0                                 | 1             | Bit                                   |
| M1                                 | 1             | Bit                                   |
| PROFINETASCII/requestParameter     | 0             | Bit                                   |
| PROFINETASCII/parameterReadSuccess | 1             | Bit                                   |
| PROFINETASCII/parameterReadError   | 0             | Bit                                   |
| PROFINETASCII/parameterValue       |               | Word[Unsigned]/Bit String[16-bit] [5] |
| [0]                                | 268           | Word[Unsigned]/Bit String[16-bit]     |
| [1]                                | 0             | Word[Unsigned]/Bit String[16-bit]     |
| [2]                                | 102           | Word[Unsigned]/Bit String[16-bit]     |
| [3]                                | 2013          | Word[Unsigned]/Bit String[16-bit]     |
| [4]                                | 2606          | Word[Unsigned]/Bit String[16-bit]     |


### 3.10.3 Changing parameters (Sequence 2)

#### Creating the request

The format of the write request is as follows:

| Byte no. | Description           | Value   |
|----------|-----------------------|---|
| 0        | Request ID            | 0x02  |
| 1        | Request reference     | 0x01-0xFF   |
| 2        | No. of parameters     | 0x01  |
| 3        | DO-ID                 | 0x01  |
| 4        | No. of elements       | 0x00  |
| 5        | Attribute value       | 0x10 (value attribute)  |
| 6-7      | Parameter number      | Byte swapped PNU  |
| 8-9      | Subindex (irrelevant) | 0x00  |
| 10       | No. of values         | 0x01  |
| 11       | Format                | 0x06 (UINTeger16 for all inverter parameters)<br>See data format type table |
| 12-13    | Set value             | Byte swapped set value  |

Modify the ladder block preparing the content of the request.



### Reading the response


A positive response consists of just 4 bytes of data in the following format:

| Byte no. | Description       | Value                          |
|----------|-------------------|--------------------------------|
| 0        | Request ID        | 0x02                           |
| 1        | Request reference | 0x01-0xFF (same as in request) |
| 2        | No. of parameters | 0x01                           |
| 3        | DO-ID             | 0x01                           |

In case of a negative response, the format is as follows:


| Byte no. | Description       | Value                                      |
|----------|-------------------|--|
| 0        | Request ID        | 0x82                                       |
| 1        | Request reference | 0x01-0xFF (same as in request)             |
| 2        | No. of parameters | 0x01                                       |
| 3        | DO-ID             | 0x01                                       |
| 4        | No. of values     | 0x01                                       |
| 5        | Format            | 0x44 (error)                               |
| 6-7      | Error value       | Byte swapped error value (see error table) |

Modify the code reading the response data. A successful parameter write is best identified by the request ID. An example procedure how to process the response is shown below.




### Executing example requests

To perform a parameter write, set the PNU of the parameter that will be changed to *requestParameterNo*. Assuming this is inverter parameter 15 (Jog frequency), add the offset 5096 and write the result to this variable. Set variable *requestParameterValue* to the requested value. The value that will be set, will be the output of multiplication of the set value, and the minimum setting increments, as according to the parameter list in the inverter manual. For parameter 15, the minimum setting increment is 0.01Hz. If a jog frequency of 5Hz is to be set, set *requestParameterValue* to 500. Finally execute the request by setting bit *requestParameter* to ON. A successful write will result in setting of the *parameterWriteSuccess* bit.



| Device/Label                        | Current Value | Data Type                         |
|-------------------------------------|---------------|-----------------------------------|
| PROFINETASCII/requestParameter      | 0             | Bit                               |
| PROFINETASCII/requestParameterNo    | 5111          | Word[Unsigned]/Bit String[16-bit] |
| PROFINETASCII/requestParameterValue | 500           | Word[Unsigned]/Bit String[16-bit] |
| PROFINETASCII/parameterWriteSuccess | 1             | Bit                               |
| PROFINETASCII/parameterWriteError   | 0             | Bit                               |
| PROFINETASCII/errorValue            | 0             | Word[Unsigned]/Bit String[16-bit] |

Test receiving a negative response, by trying to write an out of range value. After trying to write 0xFFFF as the value of parameter 15, a negative response is received with error code 0x02 (LOW\_OR\_HIGH\_LIMIT\_EXCEEDED), which is the expected behavior.




| Device/Label                        | Current Value | Data Type                         |
|-------------------------------------|---------------|-----------------------------------|
| PROFINETASCII/requestParameter      | 0             | Bit                               |
| PROFINETASCII/requestParameterNo    | 5111          | Word[Unsigned]/Bit String[16-bit] |
| PROFINETASCII/requestParameterValue | 65535         | Word[Unsigned]/Bit String[16-bit] |
| PROFINETASCII/parameterWriteSuccess | 0             | Bit                               |
| PROFINETASCII/parameterWriteError   | 1             | Bit                               |
| PROFINETASCII/errorValue            | 2             | Word[Unsigned]/Bit String[16-bit] |

### 3.11 GX Works2 Network Detect

The *Net\_Detect* function block provided with the library generated by GX Configurator PN can be used to detect devices on the PROFINET network. In chapter Profinet Controller setup using CCPU, it is only necessary to create a new configuration, download it to the C Controller and update the GX Works 2 Project (there is no need to setup any PROFINET devices). Basing this chapter on the GX Works 2 project created in chapter Preparing the GX Works2 Project, makes it possible to detect the A8NPRT-2P option card, as well as any other PROFINET IO devices on the network. For this example, extended information about the PROFINET devices will not be requested. Information on how to do this is supplied with the PROFINET controller manual.

Create a new ladder block, that will be responsible for creating the network detect request.



Compile and download the project to the PLC. Turning on the *req* bit will trigger the network detect. After the *BUSY* output turns off, the *VALID* output variable is ON for one scan, and it is possible to read the state of the network in output *STATUS*, and an array of detected PROFINET devices in global variable *ProfinetDetect* (if the naming convention from chapter Preparing the GX Works2 Project was used). The *STATUS* word is described below:

| Value | Description                                       |
|-------|---|
| 0     | Status OK   |
| 1     | Profinet stack not started                        |
| 4     | Reception buffer too small (stack internal error) |
| 5     | No more IO-device                                 |
| 6     | "Network detection" service never called          |


An example execution result is presented below:

| Device/Label                   | Current Value | Data Type                                | Class       | Device | Address    | Comment |
|--------------------------------|---------------|--|-------------|--------|------------|---------|
| PROFINET_IO_ME1PN1FW_Q/req     | 1             | Bit                                      | VAR         | M8183  | %MX0.8183  |         |
| ProfinetDetect                 |               | tPN_DEVICE_DETECT_DATA [1]               | VAR_GLOB... |        |            |         |
| [1]                            |               | tPN_DEVICE_DETECT_DATA                   |             |        |            |         |
| VendorID                       | 268           | Word[Unsigned]/Bit String[16-bit]        |             | D12277 | %MW0.12277 |         |
| DeviceID                       | 2050          | Word[Unsigned]/Bit String[16-bit]        |             | D12278 | %MW0.12278 |         |
| IP_Address                     | 3232236305    | Double Word[Unsigned]/Bit String[32-bit] |             | D12279 | %MD0.12279 |         |
| Subnetmask                     | 4294967040    | Double Word[Unsigned]/Bit String[32-bit] |             | D12281 | %MD0.12281 |         |
| Gateway                        | 0             | Double Word[Unsigned]/Bit String[32-bit] |             | D12283 | %MD0.12283 |         |
| MAC_Address_Bytes1,2           | 12288         | Word[Unsigned]/Bit String[16-bit]        |             | D12285 | %MW0.12285 |         |
| MAC_Address_Bytes3,4           | 2577          | Word[Unsigned]/Bit String[16-bit]        |             | D12286 | %MW0.12286 |         |
| MAC_Address_Bytes5,6           | 64279         | Word[Unsigned]/Bit String[16-bit]        |             | D12287 | %MW0.12287 |         |
| PROFINET_IO_ME1PN1FW_Q/stat... | 0             | Word[Unsigned]/Bit String[16-bit]        | VAR         | D12275 | %MW0.12275 |         |


## 3.12 TIA Portal Telegram 1 example

This chapter describes running the inverter through the A8PRT-2P Profinet option card using TIA Portal with telegram 1 communication.


- ① Start with a new project.




- ② Select Add new device from the Project tree section. In the new window select the appropriate PLC model and click OK to add it to the project. Select the power supply from the hardware catalog on the right side of the screen.




- ③ From the top menu select Options and Install general station description file (GSD). Search for the GSD file supplied with this manual, click Install and follow instructions to add the option card to the hardware library.




- ④ After finishing installation and returning to the main window, switch to Network view.




- ⑤ From the hardware catalog on the right side of the screen, expand Other field devices => Profinet IO => Drives => HMS Industrial Networks => A8PRT-2P and add RT to the project by dragging it to an empty space.




- ⑥ Drag a line from the slave connection node to the PLC connection node to make the PROFINET connection.




The result should look like on the screenshot below:




- ⑦ Double click on A8NPRT-2P from the device overview to bring up the Properties panel. From the hardware catalog expand Telegrams and drag Telegram 1 to the available slot.




- ⑧ Change the I address for Module Access Point to start at 0, and the I and Q address for Standard Telegram 1 to start at 1. The result should look like below:




- ⑨ Double click on the PROFINET device to show the properties tab. Enter the PROFINET interface [X1] node. Scroll down to the Ethernet addresses section. Make sure the appropriate subnet is selected, enter the IP address of the A8NPRT-2P option card (192.168.3.17). In the PROFINET section, enter the device name (a800inverter) and the device number (17).




- ⑩ Return to device view, and click on the PLC. In the Properties tab, expand the PROFINET node, and add the IP address of the PROFINET controller. For this example use address 192.168.3.10.



- ⑪ From the project tree select Program blocks and double click on Main to start editing the program. With this setup STW1 is available under QW1, NSOLL\_A under QW3, ZSW1 under IW1, and NIST\_A under IW3.



- ⑫ After powering up the inverter and PROFINET controller, connection will be established. Expect to see bit 6 (Switching On inhibited) set in ZSW1. Below is a simplified state diagram, dependent on control word 1 (STW1).




Control Word 1 (STW1) description

| State / Bit combination | Bit 10         | Bit 7             | Bit 3            | Bit 2         | Bit 1         | Bit 0 |
|-------------------------|----------------|-------------------|------------------|---------------|---------------|-------|
| Description             | Control By PLC | Fault acknowledge | Enable operation | No quick stop | No coast stop | On    |
| Switching On Inhibited  | -              | -                 | -                | -             | 0             | -     |
| Ready To Switch On      | -              | -                 | -                | 1             | 1             | -     |
| Switched On             | -              | -                 | -                | 1             | 1             | 1     |
| Operation               | -              | -                 | 1                | 1             | 1             | 1     |
| Rotation                | 1              | -                 | 1                | 1             | 1             | 1     |
| Fault reset             | -              | 0 => 1            | -                | -             | -             | -     |

Both No Coast Stop and No Quick Stop need to be set to reset the Switching On Inhibited bit in ZSW1. To do this, set bits 1 and 2 in STW1, that is bit 1 and 2 in QW1.


Input the following ladder block to allow the inverter to enter “Ready For Switching On” status, after connection is established, and initialization command is given (M0.0).




- ⑬ This initialization will result in setting bit 0 in ZSW1 (Ready To Switch On). We can now switch on the inverter, and start operation. To do this, enable bits 0 (ON/Off), 3 (enable operation), and 10 (Control By PLC); while leaving bits 1 and 2 enabled.

In the same ladder block, set the desired rotation frequency. Assuming the motor is rated for 50 Hz (inverter parameter 3) and a frequency of 10 Hz is the target run frequency (20% of the rated motor speed); the value in Profidrive to allow full power is 16384, so in order to set 20% of the rated motor speed as the run frequency, set value 3277 to the NSOLL\_A (QW3) output (3276,8 round to 3277).

Add the following ladder block to enable rotation command after initialization, and giving rotation command (M0.1).



- ⑭ Finally, add the code to stop the drive, when M0.1 is reset. In a new ladder block, check whether the first 3 bits of ZSW1 are ON. This condition means that the drive is in operation mode. If this condition is met, and M1 is not ON, reset the set point speed to zero, and set STW1 as 6.



- ⑮ Compile, and write the program and parameters to the PLC. After resetting the PLC, and powering up the inverter, set bits M0.0 and M0.1 to get the inverter up and running.


telegram1 > PLC\_1 [CPU 315-2 PN/DP] > Watch and force tables > Watch table\_1

|   | Name             | Address   | Display format | Monitor value | Modify value |                                     | Comr                                |
|---|------------------|-----------|----------------|---------------|--------------|-------------------------------------|-------------------------------------|
| 1 | "Initialize"     | %M0.0     | Bool           | TRUE          | TRUE         | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> |
| 2 | "RotationCom..." | %M0.1     | Bool           | TRUE          | TRUE         | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> |
| 3 |                  | %IW1      | DEC            | 33591         |              | <input type="checkbox"/>            | <input type="checkbox"/>            |
| 4 | "STW1"           | %QW1      | DEC            | 1039          |              | <input type="checkbox"/>            | <input type="checkbox"/>            |
| 5 | "NSOLL_A"        | %QWB      | DEC            | 3277          |              | <input type="checkbox"/>            | <input type="checkbox"/>            |
| 6 |                  | <Add new> |                |               |              | <input type="checkbox"/>            | <input type="checkbox"/>            |


### 3.13 TIA Portal Telegram 102 example

This chapter describes running the inverter through the A8NPRT-2P PROFINET option card using Siemens TIA with telegram 102 (custom) communication. First perform the setup using telegram 1.

- ① Enter the device view of the PROFINET option card and delete Standard Telegram 1 from the device overview.




- ② Now drag Telegram 102 (Custom) from the Hardware Catalog to the empty slot. Change the starting I and Q address of Telegram 102 to 1, and the starting I address of the Module Access Point to 0.




- ③ After double clicking on the telegram and selecting Module parameters node from the properties tab, it is possible to setup the input and outputs of the telegram. There are 18 inputs and outputs used in this telegram, one of each is reserved for control/status word (leaving 17 inputs/outputs free for custom setup).

The setup of the telegram is done by entering signal/parameter numbers into the right column. All monitor data can be viewed as input, and some of the profile parameters as input/output. Please keep in mind, that not all parameters can be accessed via cyclic communication. The PROFIdrive parameter numbers (PNU) available for use are listed in the Data Exchange subchapters 9.1 to 9.4. An example setup is provided below:



| Slot         | Description            | PNU   |
|--------------|------------------------|-------|
| Output PZD/2 | Speed set point        | 14317 |
| Input PZD/2  | Actual speed set point | 14319 |
| Input PZD/3  | Output frequency       | 9193  |
| Input PZD/4  | Output voltage         | 9195  |
| Input PZD/5  | Actual operation time  | 9215  |

- ④ Compile the project and download it to the PLC. The additional monitor data can be viewed in the appropriate IW address.



## 3.14 TIA Portal Acyclic communication example

This chapter describes using acyclic communication through the A8NPRT-2P PROFINET option card using TIA Portal. It contains examples of reading and writing individual parameters. First perform the setup using telegram 1.

The process of acyclic communication parameter read consists of a write request, and a response read, performed using instructions *WRREC* and *RDREC*.

### 3.14.1 Reading a parameter (Sequence 1)

#### Preparing structure of write request, and read response

Start by preparing the structure for the write request. The data request has the following format:

| Byte no. | Description       | Value                  |
|----------|-------------------|------------------------|
| 0        | Request ID        | 0x01                   |
| 1        | Request reference | 0x01-0xFF              |
| 2        | No. of parameters | 0x01                   |
| 3        | DO-ID             | 0x01                   |
| 4        | No. of elements   | 0x00                   |
| 5        | Attribute value   | 0x10 (value attribute) |
| 6-7      | Parameter number  | Byte swapped PNU       |


Request reference is any valid number, this value is mirrored back in the response and can be used to distinguish multiple requests. Once this request is processed successfully, a read request can be issued. The response of this request will contain the actual parameter value. The format of a positive response is as follows:

| Byte no. | Description       | Value                          |
|----------|-------------------|--------------------------------|
| 0        | Request ID        | 0x01                           |
| 1        | Request reference | 0x01-0xFF (same as in request) |
| 2        | No. of parameters | 0x01                           |
| 3        | DO-ID             | 0x01                           |
| 4        | No. of values     | 0x01                           |
| 5        | Format            | See data format type table     |
| 6-7      | Parameter value   | Byte swapped parameter value   |

In case of a negative response, the format is:

| Byte no. | Description       | Value                                      |
|----------|-------------------|--|
| 0        | Request ID        | 0x81                                       |
| 1        | Request reference | 0x01-0xFF (same as in request)             |
| 2        | No. of parameters | 0x01                                       |
| 3        | DO-ID             | 0x01                                       |
| 4        | No. of values     | 0x01                                       |
| 5        | Format            | 0x44 (error)                               |
| 6-7      | Error value       | Byte swapped error value (see error table) |

The content of the data request will be contained in a data block structure. Expand the PLC in the project tree and add a new block.



The data block will be added to the program blocks with the specified name. Add two structures (*RequestRecord* and *ResponseRecord*) to the data block. Create the structure of the records according to the specification, like on the screenshot below. Enter the start value for the variables so that the fields don't need to be initialized in the user program.



|    | Name           | Data type | Offset | Start value | Retain                              | Visible in ...                      | Setpoint                 |
|----|----------------|-----------|--------|-------------|-------------------------------------|-------------------------------------|--------------------------|
| 1  | Static         |           |        |             | <input type="checkbox"/>            | <input type="checkbox"/>            | <input type="checkbox"/> |
| 2  | RequestRecord  | Struct    | 0.0    |             | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input type="checkbox"/> |
| 3  | ReferenceID    | Byte      | 0.0    | 01          | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input type="checkbox"/> |
| 4  | RequestID      | Byte      | 1.0    | 01          | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input type="checkbox"/> |
| 5  | Axis           | Byte      | 2.0    | 1           | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input type="checkbox"/> |
| 6  | NoOfParameters | Byte      | 3.0    | 1           | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input type="checkbox"/> |
| 7  | Attribute      | Byte      | 4.0    | 16#10       | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input type="checkbox"/> |
| 8  | NoOfIndices    | Byte      | 5.0    | 1           | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input type="checkbox"/> |
| 9  | PNU            | Int       | 6.0    | 5097        | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input type="checkbox"/> |
| 10 | Index          | Int       | 8.0    | 0           | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input type="checkbox"/> |
| 11 | ResponseRecord | Struct    | 10.0   |             | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input type="checkbox"/> |
| 12 | ReferenceID    | Byte      | 0.0    | 16#0        | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input type="checkbox"/> |
| 13 | ResponseID     | Byte      | 1.0    | 16#0        | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input type="checkbox"/> |
| 14 | Axis           | Byte      | 2.0    | 16#0        | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input type="checkbox"/> |
| 15 | NoOfParameters | Byte      | 3.0    | 16#0        | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input type="checkbox"/> |
| 16 | Format         | Byte      | 4.0    | 16#0        | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input type="checkbox"/> |
| 17 | NoOfValues     | Byte      | 5.0    | 16#0        | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input type="checkbox"/> |
| 18 | Value          | Int       | 6.0    | 0           | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input type="checkbox"/> |
| 19 | ErrorDetails   | Int       | 8.0    | 0           | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input type="checkbox"/> |

### Creating the request


Proceed to create the user program for reading the parameter value. A state machine architecture is used for the process of creating, receiving and processing acyclic communication. The current state of the state machine is held in PLC tag *state*. A description of each state used in this example is provided below:

| State | Description  |
|-------|--|
| 1     | Send write request, wait for BUSY = 0              |
| 2     | Write request sent, read results                   |
| 3     | Write request sent successfully, send read request |
| 4     | Wait for BUSY = 0 (Read request)                   |
| 5     | Read request sent, read results                    |
| 6     | Results read                                       |
| 7     | Successfully read requested PNU value              |
| 10    | Write request error                                |
| 11    | Read request error                                 |
| 12    | Parameter read error (negative response)           |


Start by adding a new network that will contain the instructions to issue the actual write and read requests.




It will now be possible to reference the inputs and outputs of the function block instances, making it easier to create the program. Proceed to prepare the sequence. Add a new network in the user program that will start the state machine sequence. Setting *ParameterRequest* will start the state machine from state 1, initialize all used variables (*readStatus*, *readValue*, *writeStatus*), copy the requested PNU from tag *requestedPNU* to the data structure, and trigger the write request (by setting the *REQ* input of the *WRREC* function block).




The *BUSY* output of *WRREC* will immediately turn ON. Once it turns OFF, proceed to reading the result of the write request (state 2).




Expect to see either output *DONE* or *ERROR* of *WRREC* in an ON state. If *DONE* is ON, the write request was performed successfully, reset the *REQ* input, and proceed to creating the read request (state 3). If the *ERROR* output is ON, check the *STATUS* output to read the error. If the status is equal to 0xDE80B500, the result is not yet ready. In this case, do nothing and wait for the actual result. In every other case, save the status to tag *writeStatus* and enter state 10, indicating that a write request error occurred.




To initiate the read request, set input *REQ* of function block *RDREC*. Enter state 4, and wait for the *BUSY* output to turn off. Once this condition is met, enter state 5 to check the results of the read request.



Expect to see either output *DONE* or *ERROR* of *RDREC* in an ON state. If *DONE* is ON, the read request was performed successfully, reset the *REQ* input, enter state 6 to process the response. If the *ERROR* output is ON, check the *STATUS* output to read the error. If the status is equal to 0xDF80B500, the result is not yet ready. In this case, do nothing and wait for the actual result. In every other case, save the status to tag *readStatus* and enter state 11, indicating that a read request error occurred.



Finally process the received response. Check the *ResponseID* field of the *ResponseRecord*. A value of 1 indicates that the request was performed successfully. In this case move the *Value* field of this structure to the *readValue* tag. Enter state 7 to indicate a successful parameter read. If the *responseID* is equal to 0x81, then a negative response was received. Save the error value (also the *Value* field of the structure) to the *readError* tag. Enter state 12 to signal a negative response.



### Executing example requests

After compiling the program, and writing it to the PLC, it is possible to execute parameter read requests. First, get the inverter running by setting bits M0 and M1. Now read the actual frequency by writing PNU 9193 to *requestPNU* and setting bit *ParameterRequest*. The result should be a value of 1000 in *readValue*, which corresponds to 10Hz.

Profinet Acyclic Read ▶ PLC\_1 [CPU 315-2 PN/DP] ▶ Watch and force tables ▶ Watch table\_1

|   | Name               | Address | Display format | Monitor value | Modify value |                                     |
|---|--------------------|---------|----------------|---------------|--------------|-------------------------------------|
| 1 | "Initialize"       | %M0.0   | Bool           | TRUE          | TRUE         | <input checked="" type="checkbox"/> |
| 2 | "RotationComma..." | %M0.1   | Bool           | TRUE          | TRUE         | <input checked="" type="checkbox"/> |
| 3 | "state"            | %MW2    | DEC+/-         | 7             | 0            | <input checked="" type="checkbox"/> |
| 4 | "requestedPNU"     | %MW18   | DEC+/-         | 9193          | 9193         | <input checked="" type="checkbox"/> |
| 5 | "ParameterRequest" | %M0.2   | Bool           | FALSE         | TRUE         | <input checked="" type="checkbox"/> |
| 6 | "writeStatus"      | %MD4    | Hex            | 16#0000_0000  | 16#0000_0000 | <input type="checkbox"/>            |
| 7 | "readStatus"       | %MD10   | Hex            | 16#0000_0000  | 16#0000_0000 | <input type="checkbox"/>            |
| 8 | "readValue"        | %MW14   | DEC+/-         | 1000          |              | <input type="checkbox"/>            |
| 9 | <Add new>          |         |                |               |              | <input type="checkbox"/>            |

Try testing a negative response by changing the axis number to 0x10. Notice, that after executing the sequence, state 12 is active. An error code of 0x19 (AXIS\_DO\_NONEXISTENT) is expected.

Profinet Acyclic Read ▶ PLC\_1 [CPU 315-2 PN/DP] ▶ Watch and force tables ▶ Watch table\_1

|    | i | Name               | Address   | Display format | Monitor value                            | Modify value |                                       |
|----|---|--------------------|-----------|----------------|--|--------------|---------------------------------------|
| 1  |   | "Initialize"       | %MO.0     | Bool           | <input checked="" type="checkbox"/> TRUE | TRUE         | <input checked="" type="checkbox"/> ⚠ |
| 2  |   | "RotationComma...  | %MO.1     | Bool           | <input checked="" type="checkbox"/> TRUE | TRUE         | <input checked="" type="checkbox"/> ⚠ |
| 3  |   | "state"            | %MW2      | DEC+/-         | 12                                       | 0            | <input checked="" type="checkbox"/> ⚠ |
| 4  |   | "requestedPNU"     | %MW18     | DEC+/-         | 6401                                     | 6401         | <input checked="" type="checkbox"/> ⚠ |
| 5  |   | "ParameterRequest  | %MO.2     | Bool           | <input type="checkbox"/> FALSE           | TRUE         | <input checked="" type="checkbox"/> ⚠ |
| 6  |   | "writeStatus"      | %MD4      | Hex            | 16#0000_0000                             | 16#0000_0000 | <input type="checkbox"/>              |
| 7  |   | "readStatus"       | %MD10     | Hex            | 16#0000_0000                             | 16#0000_0000 | <input type="checkbox"/>              |
| 8  |   | "readValue"        | %MW14     | DEC+/-         | 0  |              | <input type="checkbox"/>              |
| 9  |   | "DB".RequestReco.. | %DB1.DBB2 | Hex            | 16#10                                    | 16#10        | <input checked="" type="checkbox"/> ⚠ |
| 10 |   | "readError"        | %MW20     | Hex            | 16#0019                                  |              | <input type="checkbox"/>              |
| 11 |   | <Add new>          |           |                |  |              | <input type="checkbox"/>              |

### 3.14.2 Changing parameters (Sequence 2)

This example will be based off of the previous example (Reading a parameter – Sequence 1), as the changes needed are minimal.

#### Preparing structure of write request, and read response

Start by preparing the structure for the write request. The data request has the following format:

| Byte no. | Description           | Value   |
|----------|-----------------------|---|
| 0        | Request ID            | 0x02  |
| 1        | Request reference     | 0x01-0xFF   |
| 2        | No. of parameters     | 0x01  |
| 3        | DO-ID                 | 0x01  |
| 4        | No. of elements       | 0x00  |
| 5        | Attribute value       | 0x10 (value attribute)  |
| 6-7      | Parameter number      | PNU to modify   |
| 8-9      | Subindex (irrelevant) | 0x00  |
| 10       | No. of values         | 0x01  |
| 11       | Format                | 0x06 (UINT16 for all inverter parameters)<br>See data format type table |
| 12-13    | Set value             | PNU value to write  |


Once this request is processed successfully, a read request can be issued. The response of this request will determine whether the parameter write was successful. The format of a positive response is as follows:

| Byte no. | Description       | Value                          |
|----------|-------------------|--------------------------------|
| 0        | Request ID        | 0x02                           |
| 1        | Request reference | 0x01-0xFF (same as in request) |
| 2        | No. of parameters | 0x01                           |
| 3        | DO-ID             | 0x01                           |

In case of a negative response, the format is as follows:


| Byte no. | Description       | Value                          |
|----------|-------------------|--------------------------------|
| 0        | Request ID        | 0x82                           |
| 1        | Request reference | 0x01-0xFF (same as in request) |
| 2        | No. of parameters | 0x01                           |
| 3        | DO-ID             | 0x01                           |
| 4        | No. of values     | 0x01                           |
| 5        | Format            | 0x44 (error)                   |
| 6-7      | Error value       | Error value (see error table)  |

Modify the data structures created in the previous example to account for the changes (note the changes in start value fields):




### Creating the request


Modify the ladder network initiating the sequence, to set the value of field *SetValue* in the *RequestRecord* structure. This is the value that will be written to the requested PNU.



Modify the network responsible for processing of the read request response. A positive response will have ID 0x02, while a negative response ID 0x82.



Finally change the length of the write request to 14 bytes.



### Executing example requests

To perform a parameter write, set the PNU of the parameter to change in *requestedPNU*. As an example, to change parameter 15 (Jog frequency), add the offset 5096 and write the result (5111) to variable *requestedPNU*. The value that will be set, will be the output of multiplication of the set value, and the minimum setting increments, as according to the parameter list in the inverter manual. For parameter 15, the minimum setting increment is 0.01Hz. If a jog frequency of 5Hz is requested, set *writeValue* to 500. Finally execute the request by setting bit *ParameterRequest* to ON. A successful write will result in entering state 7.

Profinet Acyclic Write > PLC\_1 [CPU 315-2 PN/DP] > Watch and force tables > Watch table\_1

|    | i | Name               | Address   | Display format | Monitor value                  | Modify value |                                     |
|----|---|--------------------|-----------|----------------|--------------------------------|--------------|-------------------------------------|
| 1  |   | "Initialize"       | %M0.0     | Bool           | <input type="checkbox"/> FALSE | FALSE        | <input type="checkbox"/>            |
| 2  |   | "RotationCommand"  | %M0.1     | Bool           | <input type="checkbox"/> FALSE | FALSE        | <input type="checkbox"/>            |
| 3  |   | "state"            | %MW2      | DEC+/-         | 7                              | 0            | <input type="checkbox"/>            |
| 4  |   | "requestedPNU"     | %MW18     | DEC+/-         | 5111                           | 5111         | <input checked="" type="checkbox"/> |
| 5  |   | "ParameterRequest" | %M0.2     | Bool           | <input type="checkbox"/> FALSE | TRUE         | <input checked="" type="checkbox"/> |
| 6  |   | "writeStatus"      | %MD4      | Hex            | 16#0000_0000                   | 16#0000_0000 | <input type="checkbox"/>            |
| 7  |   | "readStatus"       | %MD10     | Hex            | 16#0000_0000                   | 16#0000_0000 | <input type="checkbox"/>            |
| 8  |   | "readError"        | %MW20     | DEC+/-         | 0                              |              | <input type="checkbox"/>            |
| 9  |   | "writeValue"       | %MW22     | DEC+/-         | 500                            | 500          | <input checked="" type="checkbox"/> |
| 10 |   |                    | <Add new> |                |                                |              | <input type="checkbox"/>            |

Test receiving a negative response, by trying to write an out of range value. After trying to write 0xFFFF as the value of parameter 15, state 12 will be entered indicating a negative response with error code 0x02 (LOW\_OR\_HIGH\_LIMIT\_EXCEEDED) stored in *readError* tag, which is the expected behavior.

Profinet Acyclic Write > PLC\_1 [CPU 315-2 PN/DP] > Watch and force tables > Watch table\_1

|    | i | Name               | Address   | Display format | Monitor value                  | Modify value |                                     |
|----|---|--------------------|-----------|----------------|--------------------------------|--------------|-------------------------------------|
| 1  |   | "Initialize"       | %M0.0     | Bool           | <input type="checkbox"/> FALSE | FALSE        | <input type="checkbox"/>            |
| 2  |   | "RotationCommand"  | %M0.1     | Bool           | <input type="checkbox"/> FALSE | FALSE        | <input type="checkbox"/>            |
| 3  |   | "state"            | %MW2      | DEC+/-         | 12                             | 0            | <input type="checkbox"/>            |
| 4  |   | "requestedPNU"     | %MW18     | DEC+/-         | 5111                           | 5111         | <input checked="" type="checkbox"/> |
| 5  |   | "ParameterRequest" | %M0.2     | Bool           | <input type="checkbox"/> FALSE | TRUE         | <input checked="" type="checkbox"/> |
| 6  |   | "writeStatus"      | %MD4      | Hex            | 16#0000_0000                   | 16#0000_0000 | <input type="checkbox"/>            |
| 7  |   | "readStatus"       | %MD10     | Hex            | 16#0000_0000                   | 16#0000_0000 | <input type="checkbox"/>            |
| 8  |   | "readError"        | %MW20     | DEC+/-         | 2                              |              | <input type="checkbox"/>            |
| 9  |   | "writeValue"       | %MW22     | Hex            | 16#FFFF                        | 16#FFFF      | <input checked="" type="checkbox"/> |
| 10 |   |                    | <Add new> |                |                                |              | <input type="checkbox"/>            |


## 3.15 SIMATIC STEP7 example

### 3.15.1 Creating a Configuration

This section describes a simple example on how to configure a PROFINET network including an A8NPRT\_2P PROFINET Option Board using the SIMATIC STEP7 configuration tool. Please consult the SIMATIC STEP7 instruction manual or online help for further information on how to use the tool.

The configuration is created offline and downloaded to the network when it is finished.


- ① Open SIMATIC STEP7.
- ② Select Options - Install GSD.




- ③ Browse for the correct GSD-file to use with the option board. Select file and click Install.




- ④ Select PLC and drag an instance of the selected PLC into the configuration window.




- ⑤ Locate the option board in the HW catalog (PROFINET IO -> Additional Field Devices -> Drives).




- ⑥ Drag and drop an instance of the option board to the configuration.




- ⑦ With the option board selected, right click and open Object Properties from the menu in the pop-up window. Select the General tab. Enter Device Name (Station Name) and check "Assign IP address via IO controller".





- ⑧ Select Parameters tab. Select subnet and enter the IP address of the option board. This address will be assigned to the option board by the PLC when the configuration is downloaded to the network. Click OK.



- ⑨ Select and drag and drop telegram to option board. The telegrams are found in the HW catalog with the option board.



- ⑩ With the new telegram instance selected, right click and open the Telegram Properties window from the pop-up menu. Enter a name for the telegram and map the cyclic data in the telegram.





- ⑪ Repeat until all devices are entered into the configuration.


### 3.15.2 Download Configuration to the PLC

The configuration of the PROFINET network is built offline. To download the configuration to the PLC that acts as master for the network, follow the steps below:


- ① Connect to network.
- ② Select a node and open the Edit Ethernet Node window.




- ③ Click Browse to start scanning for devices on the network. This will produce a list of available units.




- ④ Find the correct unit by the MAC address. Select and confirm using the button "Flash".



- ⑤ Allocate station name (device name). The PLC will allocate correct IP address at download. Repeat steps 4 and 5 for each unit in the network.



- ⑥ Download configuration to network, either by selecting *PLC -> Download...* or by clicking on the download symbol.



### 3.15.3 Run

Set the PLC in RUN mode.



## 4. Inverter Settings

### 4.1 Inverter Parameters

The inverter parameters are critical for overall operation of the end-to-end communication system. Some of these parameters must be set to specific values, and some may have multiple allowable settings depending on the desired operation of the overall application. It is important to understand the manner in which the parameters will impact successful communications with, and control of the inverter.

The inverter parameters can be changed either via the handheld parameter unit or via the web pages of the option board. The handheld parameter unit is described in the user manual for the FR-A800 or FR-F800 series, and the option board web pages are described in "Web Pages" on page 92.

---

**Note:** The scaling of the parameter values are different if you use the parameter unit or the option board web pages, for further information see "Parameter Data" on page 95.

---

## 4.2 Option Board Parameters

The option board parameters are stored in the inverter. At startup they are transferred from the inverter to the option board and can be changed using the parameter unit or the option board web pages.

| No (dec)    | No (hex)    | Parameter Name.          | Description  |
|-------------|-------------|--------------------------|--|
| 1300        | 514h        | Option parameter 1       | General settings, see "Parameter 1300 (514h, General Settings)" on page 86                               |
| 1301        | 515h        | Option parameter 2       | Ethernet Host Settings, see "Parameter 1301 (515h, Ethernet Host Settings)" on page 87                   |
| 1302        | 516h        | Option parameter 3       | Network Type <sup>1</sup>  |
| 1303        | 517h        | Option parameter 4       | Serial number (low word) <sup>2</sup>  |
| 1304        | 518h        | Option parameter 5       | Serial number (high word) <sup>2</sup>   |
| 1305        | 519h        | Option parameter 6       | IP address (first byte), see "Parameters 1305 - 1308 (519h - 51Ch, IP Address)" on page 87               |
| 1306        | 51Ah        | Option parameter 7       | IP address (second byte)   |
| 1307        | 51Bh        | Option parameter 8       | IP address (third byte)  |
| 1308        | 51Ch        | Option parameter 9       | IP address (fourth byte)   |
| 1309        | 51Dh        | Option parameter 10      | Subnet mask (first byte), see "Parameters 1309 - 1312 (51Dh - 520h, Subnet Mask)" on page 87             |
| 1310        | 51Eh        | Option parameter 11      | Subnet mask (second byte)  |
| 1311        | 51Fh        | Option parameter 12      | Subnet mask (third byte)   |
| 1312        | 520h        | Option parameter 13      | Subnet mask (fourth byte)  |
| 1313        | 521h        | Option parameter 14      | Gateway address (first byte), see "Parameters 1313 - 1316 (521h - 524h, Gateway Address)" on page 87     |
| 1314        | 522h        | Option parameter 15      | Gateway address (second byte)  |
| 1315        | 523h        | Option parameter 16      | Gateway address (third byte)   |
| 1316        | 524h        | Option parameter 17      | Gateway address (fourth byte)  |
| 1317        | 525h        | Option parameter 18      | Ethernet Communication Settings, see "Parameter 1317 (525h, Ethernet Communication Settings)" on page 88 |
| 1318 - 1343 | 526h - 53Fh | Option parameter 19 - 44 | Network specific 1 - 26  |

<sup>1</sup> During startup the option board will verify the value of this parameter. If it differs from the network type of the option board, the option board will change the parameter value to the actual network type and clear all other parameters.

<sup>2</sup> During startup the option board will verify the value of this parameter. If it differs from the serial number of the option board, the option board will change the parameter value to the actual serial number and also set the option board host name to [main-unit-name]-[serial number]

The option board and the inverter start up with default standard settings. Any changes of the parameter values during runtime, will not be available until the inverter has been restarted.

The application can more often than not be run on standard settings.

### Parameter 1300 (514h, General Settings)

Only read by the option board during startup.

| Bit    | Name                        | Default | Description   |
|--------|-----------------------------|---------|---|
| 0 - 3  | (reserved)                  | 0       | N/A   |
| 4      | Clear all Option Parameters | 0       | Will clear all option parameters and set the default values when set to 1. Resets itself to False (0) after completion. |
| 5 - 15 | (reserved)                  | 0       | N/A   |

**Parameter 1301 (515h, Ethernet Host Settings)**

Only read by the option board during startup.

**Note:** For these settings to be used, parameter 1317 (525h) has to be set to 1.

| Bit  | Name                        | Default | Description  |
|------|-----------------------------|---------|--|
| 0    | HICP                        | 0       | 0: Enables support for the HICP protocol used by the Anybus IPconfig utility.<br>1: Disables support for the HICP protocol.      |
| 1    | Web Server                  | 0       | 0: Enables the built-in web server.<br>1: Disables the built-in web server.  |
| 2    | Web ADI access <sup>1</sup> | 0       | 0: Enables access to inverter parameters from the web server.<br>1: Disables access to inverter parameters from the web servers. |
| 3    | FTP server                  | 0       | 0: Enables the built-in FTP server.<br>1: Disables the built-in FTP server.  |
| 4    | Admin mode                  | 0       | 0: Disables FTP admin mode.<br>1: Enables FTP admin mode.  |
| 5    | (reserved)                  | 0       | N/A  |
| 6    | Format file system          | 0       | 0: Default<br>1: Formats the file system. Will reset itself to False (0) after completion.                                       |
| 7-15 | (reserved)                  | 0       | N/A  |

<sup>1</sup> Web server must be enabled.

**Parameters 1305 - 1308 (519h - 51Ch, IP Address)**

These four parameters store the IP Address of the option board. Byte order is allocated as in the following example:

|                            |                     |
|----------------------------|---------------------|
| <b>IP address:</b>         | 192. 168. 111. 222  |
| <b>Parameter no (hex):</b> | 519 51A 51B 51C     |
| <b>Parameter no (dec):</b> | 1305 1306 1307 1308 |

**Parameters 1309 - 1312 (51Dh - 520h, Subnet Mask)**

These four parameters store the subnet mask. Byte order is allocated as in the following example:

|                            |                     |
|----------------------------|---------------------|
| <b>IP address:</b>         | 255. 255. 255. 0    |
| <b>Parameter no (hex):</b> | 51D 51E 51F 520     |
| <b>Parameter no (dec):</b> | 1309 1310 1311 1312 |

**Parameters 1313 - 1316 (521h - 524h, Gateway Address)**

These four parameters store the gateway address of the option board. Byte order is allocated as in the following example:

|                            |                     |
|----------------------------|---------------------|
| <b>IP address:</b>         | 192. 168. 111. 1    |
| <b>Parameter no (hex):</b> | 521 522 523 524     |
| <b>Parameter no (dec):</b> | 1313 1314 1315 1316 |

**Parameter 1317 (525h, Ethernet Communication Settings)**

Only read by the option board during startup.

---

**Note:** If the settings of parameter 1305 are to be used by the option card, this parameter must be set to 1 or 3. If DHCP is enabled, the option card will first try to receive the IP address from a DHCP server, and then fall back to the address set in inverter parameters.

---

| Bit  | Name                | Default | Values   | Description  |
|------|---------------------|---------|----------|--|
| 0    | Priority of setting | 0       | 0:<br>1: | Option board settings are used for network settings.<br>Option board parameters (inverter parameter data) are used for network settings. |
| 1    | DHCP <sup>1</sup>   | 0       | 0:<br>1: | DHCP is enabled<br>DHCP is disabled  |
| 2-15 | (reserved)          | 0       | N/A      |  |

<sup>1</sup> The value of this bit is ignored if bit 0 (Priority of setting) of the parameter is set to 0 (default).

## 4.3 Operation Mode Setting

To bring the FR-A800 or FR-F800 in Network mode, please change Pr. 340 to 1 or 10. If so the drive unit starts up in the Network operation mode after power off/on. Please refer to the FR-A800 or FR-F800 instruction manual for information.

## 5. Identifying the Option Board

A device on a PROFINET network is primarily defined by its station name (device name). To be able to take advantage of the internal web pages of the option board, the user needs to identify the option board on the network through its IP address. The PROFINET master may assign an IP address to a device, but an IP address can be assigned separately as well.

The station (device) name is assigned through the Siemens Primary Setup Tool or the “Edit ethernet node” option in STEP7.

### 5.1 Siemens Primary Setup Tool

The Siemens Primary Setup Tool can be used to find all devices on a PROFINET network. The tool is installed together with STEP7. The same functionality is available when selecting “Edit ethernet node” in STEP7.

Locate your device in the MAC address list<sup>1</sup>. This list is presented by the tool. If you select module-flash for that device, the module status LED of the device will start flashing. Set a station name for the device.

Clicking on the device will show the network settings, including the possibility to assign/change an IP address, for the device.

### 5.2 IP Address

At startup, the master will address the option board using the station name. The option board responds with (among other things) its IP address, if assigned.

An IP address can be assigned to the A8NPRT\_2P PROFINET Option Board in different ways:

- An IP address can be assigned to the option board during configuration
- The IP address, subnet mask and gateway address can be assigned using the parameter unit. For more information see “Option Board Parameters” on page 86.
- DHCP is disabled by default for the PROFINET option board, but will, if enabled, automatically assign an IP address to the option board.
- Once an initial IP address has been assigned to the device and the configuration web page can be accessed, the IP address related parameters can also be modified via the web page.

If HICP<sup>2</sup> is enabled in option board parameter 515h, the Anybus IPconfig tool<sup>3</sup> can be used to find the option board on the network.

---

<sup>1</sup> The MAC address is printed on the option board.

<sup>2</sup> For more information see “HICP (Host IP Configuration Protocol)” on page 127.

<sup>3</sup> Available for download from [www.anybus.com](http://www.anybus.com).



## 6. Embedded Web Server

### 6.1 Overview

The interface contains an embedded web server (also known as an HTTP server), which allows users to access the inverter's internal data with web browsers such as Microsoft Internet Explorer or Mozilla Firefox. In this way, the inverter can be monitored, configured and controlled from across the room or from across the globe.

To access an interface's embedded web server, either use the IPConfig Tool and select the "Open Web Interface" button when the target unit is highlighted, or just directly enter the target unit's IP address into the address (URL) field of your web browser.

The web server supports up to 20 concurrent connections and communicates through port 80.

### 6.2 Authorization

Directories can be protected from web access by placing a file called 'web\_accs.cfg' in the directory to protect.<sup>1</sup> This file shall contain a list of users that are allowed to access the directory and its subdirectories.

*File Format:*

```
Username1:Password1
Username2:Password2
...
UsernameN:PasswordN
```

— List of approved users.

```
[AuthName]
(message goes here)
```

— Optionally, a login message can be specified by including the key [AuthName]. This message will be displayed by the web browser upon accessing the protected directory.

The list of approved users can optionally be redirected to one or several other files.

*Example:*

In this example, the list of approved users will be loaded from 'here.cfg' and 'too.cfg'.


```
[File path]
\i\put\some\over\here.cfg
\i\actually\put\some\of\it\here\too.cfg

[AuthName]
Howdy. Password, please.
```

<sup>1</sup> For more information about the file system, see "File System and FTP Server" on page 99.

## 6.3 Web Pages


Open a web browser (IE or Firefox e.g.). Enter the IP address for the option board. The window pane below will appear:



The index page gives access to the following pages:

- Network interface
- Parameter data
- Operation panel

### 6.3.1 Network Interface



The following information is available on the network interface page:


| Name                  | Description   |
|-----------------------|---|
| Serial#               | The serial number of the option board.              |
| MAC ID                | The MAC ID of the option board.                     |
| Firmware version      | The firmware version of the option board.           |
| Uptime                | The uptime of the option board.                     |
| CPU load              | Current CPU load of the option board.               |
| PROFINET station name | The currently set station name of the option board. |

From this web page you can continue to:

- Network configuration
- Network statistics

### Network Configuration Page


The network configuration page provides an interface for configuring the network settings. The module needs a reset for the changes to take effect.



Available editable settings:

| Name        | Description   |
|-------------|---|
| IP address  | The TCP/IP settings of the module   |
| Subnet mask | Default values: 0.0.0.0   |
| Gateway     | Valid values: 0.0.0.0 - 255.255.255.255   |
| DHCP        | Enabling or disabling DHCP<br>Default: Disabled   |
| Host name   | IP address or name<br>Max 64 characters<br>Default: [inverter name]-[serial number] e.g. FR-A820-1234ABCD |
| Domain name | IP address or name<br>Max 48 characters   |

### Ethernet Statistics Page



The Ethernet statistics web page contains the following information:

| Ethernet Link |        | Description                      |
|---------------|--------|----------------------------------|
| Port 1        | Speed  | The current link speed           |
|               | Duplex | The current duplex configuration |
| Port 2        | Speed  | The current link speed           |
|               | Duplex | The current duplex configuration |

| Interface Counters | Description   |
|--------------------|---|
| In Octets          | Received bytes  |
| In Ucast packets   | Received unicast packets                                      |
| In NUCast packets  | Received non-unicast packets (broadcast and multicast)        |
| In Discards        | Received packets discarded due to no available memory buffers |
| In Errors          | Received packets discarded due to reception error             |
| In Unknown Protos  | Received packets with unsupported protocol type               |
| Out Octets         | Sent bytes  |
| Out Ucast packets  | Sent unicast packets  |
| Out NUCast packets | Sent non-unicast packets (broadcast and multicast)            |
| Out Discards       | Outgoing packets discarded due to no available memory buffers |
| Out Errors         | Transmission errors   |

### 6.3.2 Parameter Data

In the Parameter Data web page, all the parameters and cyclic monitor data of the inverter can be accessed. The available parameters correspond to parameters with PNU 5096...16388 using the PROFIdrive parameter protocol.

#### A8NPRT-2P

**Parameter data**

Number of parameters per page:

| #  | Parameter    | Value                              |                                    |
|----|--------------|------------------------------------|------------------------------------|
| 1  | Parameter# 0 | <input type="text" value="60"/>    | <input type="button" value="Set"/> |
| 2  | Parameter# 1 | <input type="text" value="12000"/> | <input type="button" value="Set"/> |
| 3  | Parameter# 2 | <input type="text" value="0"/>     | <input type="button" value="Set"/> |
| 4  | Parameter# 3 | <input type="text" value="6000"/>  | <input type="button" value="Set"/> |
| 5  | Parameter# 4 | <input type="text" value="6000"/>  | <input type="button" value="Set"/> |
| 6  | Parameter# 5 | <input type="text" value="28"/>    | <input type="button" value="Set"/> |
| 7  | Parameter# 6 | <input type="text" value="1000"/>  | <input type="button" value="Set"/> |
| 8  | Parameter# 7 | <input type="text" value="50"/>    | <input type="button" value="Set"/> |
| 9  | Parameter# 8 | <input type="text" value="50"/>    | <input type="button" value="Set"/> |
| 10 | Parameter# 9 | <input type="text" value="255"/>   | <input type="button" value="Set"/> |

|                         |                         |                         |                         |                               |
|-------------------------|-------------------------|-------------------------|-------------------------|-------------------------------|
| <a href="#">1-10</a>    | <a href="#">11-20</a>   | <a href="#">21-30</a>   | <a href="#">31-40</a>   | <a href="#">Next &gt;&gt;</a> |
| <a href="#">41-50</a>   | <a href="#">51-60</a>   | <a href="#">61-70</a>   | <a href="#">71-80</a>   |                               |
| <a href="#">81-90</a>   | <a href="#">91-100</a>  | <a href="#">101-110</a> | <a href="#">111-120</a> |                               |
| <a href="#">121-130</a> | <a href="#">131-140</a> | <a href="#">141-150</a> | <a href="#">151-160</a> |                               |
| <a href="#">161-170</a> | <a href="#">171-180</a> | <a href="#">181-190</a> | <a href="#">191-200</a> |                               |
| <a href="#">201-210</a> | <a href="#">211-220</a> | <a href="#">221-230</a> | <a href="#">231-240</a> |                               |
| <a href="#">241-250</a> | <a href="#">251-260</a> | <a href="#">261-270</a> | <a href="#">271-280</a> |                               |
| <a href="#">281-290</a> | <a href="#">291-300</a> | <a href="#">301-310</a> | <a href="#">311-320</a> |                               |
| <a href="#">321-330</a> | <a href="#">331-340</a> | <a href="#">341-350</a> | <a href="#">351-360</a> |                               |
| <a href="#">361-370</a> | <a href="#">371-380</a> | <a href="#">381-390</a> | <a href="#">391-400</a> |                               |
| <a href="#">401-410</a> | <a href="#">411-420</a> | <a href="#">421-430</a> | <a href="#">431-440</a> |                               |
| <a href="#">441-450</a> | <a href="#">451-460</a> | <a href="#">461-470</a> | <a href="#">471-480</a> |                               |
| <a href="#">481-490</a> | <a href="#">491-500</a> | <a href="#">501-510</a> | <a href="#">511-520</a> |                               |
| <a href="#">521-530</a> | <a href="#">531-540</a> | <a href="#">541-550</a> | <a href="#">551-560</a> |                               |
| <a href="#">561-570</a> | <a href="#">571-580</a> | <a href="#">581-590</a> | <a href="#">591-600</a> |                               |
| <a href="#">601-610</a> | <a href="#">611-620</a> | <a href="#">621-630</a> | <a href="#">631-640</a> |                               |
| <a href="#">641-650</a> | <a href="#">651-660</a> | <a href="#">661-670</a> | <a href="#">671-680</a> |                               |
| <a href="#">681-690</a> | <a href="#">691-700</a> | <a href="#">701-710</a> | <a href="#">711-720</a> |                               |
| <a href="#">721-730</a> | <a href="#">731-740</a> | <a href="#">741-750</a> | <a href="#">751-760</a> |                               |
| <a href="#">761-770</a> | <a href="#">771-780</a> | <a href="#">781-790</a> | <a href="#">791-800</a> |                               |
| <a href="#">801-810</a> | <a href="#">811-819</a> |                         |                         |                               |

[▶ Main](#)

Please note that all values have to be scaled to conform to the values shown in the hand-held parameter unit. The scaling factor is specific to each parameter and listed in the inverter manual. The value shown on the web page has to be multiplied by this scaling factor. The picture below shows the web pages including the scaling factor for each parameter. See "Download" on page 1 for websites where these web pages are available for download.

### A8NPRT-2P

**Parameter data**

Number of parameters per page:


| #  | Parameter                               | Unit   | Value                              |                                    |
|----|---|--------|------------------------------------|------------------------------------|
| 1  | Pr.0 Torque boost                       | 0.1%   | <input type="text" value="20"/>    | <input type="button" value="Set"/> |
| 2  | Pr.1 Maximum frequency                  | 0.01Hz | <input type="text" value="12000"/> | <input type="button" value="Set"/> |
| 3  | Pr.2 Minimum frequency                  | 0.01Hz | <input type="text" value="0"/>     | <input type="button" value="Set"/> |
| 4  | Pr.3 Base frequency                     | 0.01Hz | <input type="text" value="6000"/>  | <input type="button" value="Set"/> |
| 5  | Pr.4 Multi-speed setting (high speed)   | 0.01Hz | <input type="text" value="6000"/>  | <input type="button" value="Set"/> |
| 6  | Pr.5 Multi-speed setting (middle speed) | 0.01Hz | <input type="text" value="3000"/>  | <input type="button" value="Set"/> |
| 7  | Pr.6 Multi-speed setting (low speed)    | 0.01Hz | <input type="text" value="1000"/>  | <input type="button" value="Set"/> |
| 8  | Pr.7 Acceleration time                  | 0.1s   | <input type="text" value="0"/>     | <input type="button" value="Set"/> |
| 9  | Pr.8 Deceleration time                  | 0.1s   | <input type="text" value="0"/>     | <input type="button" value="Set"/> |
| 10 | Pr.9 Electronic thermal O/L relay       | 0.01A  | <input type="text" value="4600"/>  | <input type="button" value="Set"/> |

1-10    11-20    21-30    31-40    Next >>  
 41-50    51-60    61-70    71-80  
 81-90    91-100    101-110    111-120  
 121-130    131-140    141-150    151-160  
 161-170    171-180    181-190    191-200  
 201-210    211-220    221-230    231-240  
 241-250    251-260    261-270    271-280  
 281-290    291-300    301-310    311-320  
 321-330    331-340    341-350    351-360  
 361-370    371-380    381-390    391-400  
 401-410    411-420    421-430    431-440  
 441-450    451-460    461-470    471-480  
 481-490    491-500    501-510    511-520  
 521-530    531-540    541-550    551-560  
 561-570    571-580    581-590    591-600  
 601-610    611-620    621-630    631-640  
 641-650    651-660    661-670    671-680  
 681-690    691-700    701-710    711-720  
 721-730    731-740    741-750    751-760  
 761-770    771-780    781-790    791-800  
 801-810    811-820    821-830    831-840  
 841-850    851-860    861-870    871-880  
 881-890    891-900    901-906

▶ Main

### 6.3.3 Drive Monitor

This webpage makes it possible to monitor actual values from the device.



The Forward (Fwd), Reverse (Rev) and Stop buttons allow the user to start forward rotation or reverse rotation of the drive, as well as to stop the drive.

Using the Fwd, Rev or Stop buttons will make a confirmation window appear. Press the OK button to confirm, or the Cancel button to cancel. If the "Disable warning" checkbox is checked, no confirmation window will appear.



## 7. File System and FTP Server

### 7.1 General

The file system of the option board is used to store files used by the application firmware, e.g. configuration files.

Whenever the configuration is completed, it is suggested that a backup copy of the configuration file be downloaded from the unit to a PC. One reason for this is if it becomes necessary to restore a previous configuration at a later time. Another reason is that it may be desirable to use the same configuration for multiple units. A downloaded configuration file can be uploaded again to any compatible unit, allowing the user to easily clone multiple units with the same configuration.

Interacting with the file system is performed by use of the File Transfer Protocol (FTP). The built-in FTP server makes it easy to manage the file system using a standard FTP client, interacting with the files in the same manner as though they were traditional files stored on a local or remote PC.

Note that certain routers or firewall applications (such as Windows Firewall) can block FTP traffic. If an FTP connection to the option board cannot be established, be sure to check the computer's firewall settings during troubleshooting, and add an exception to the firewall configuration if necessary.

### 7.2 FTP Server

#### 7.2.1 Initiation

By default, the following port numbers are used for FTP communication:

- TCP, port 20 (FTP data port)
- TCP, port 21 (FTP command port)

The FTP server supports up to 8 concurrent connections.

#### 7.2.2 User Accounts

User accounts are stored in the configuration file '\ftp.cfg'. This file holds the usernames, passwords, and home directory for all users. Users are not able to access files outside of their home directory.

The FTP password protects removal and replacement of downloaded web-pages in the module even if actual web-access has separate passwords.

*File Format:*

```
User1:Password1:Homedir1
User2:Password2:Homedir2
User3:Password3:Homedir3
```

Optionally, the UserN:PasswordN-section can be replaced by a path to a file containing a list of users as follows:

*File Format ('\ftp.cfg'):*

```
User1:Password1:Homedir1
User2:Password2:Homedir2
\path\userlistA:HomedirA
\path\userlistB:HomedirB
```

The files containing the user lists shall have the following format:

*File Format:*

```
User1:Password1
User2:Password2
User3:Password3
```

---

**Notes:**

- Usernames must not exceed 15 characters in length.
  - Passwords must not exceed 15 characters in length.
  - User names and passwords must only contain printable characters in the Lower ASCII characters set (value 32 to 127). Delimiter character ':' must not be used as part of the username or password. Character '\' must not be used as the first character of the user name.
  - File must be stored using ANSI encoding.
  - If '\ftp.cfg' is missing or cannot be interpreted, all username/password combinations will be accepted and the home directory will be the FTP root (i.e. '\ftp\').
  - The home directory for a user must also exist in the file system if they should be able to log in, just adding the user information to the 'ftp.cfg' file it is not enough.
  - If 'Admin Mode' has been enabled in the Option Board parameters, all username/password combinations will be accepted and the user will have unrestricted access to the file system (i.e. the home directory will be the system root).
  - It is strongly recommended to have at least one user with root access ('\') permission. If not, 'Admin Mode' must be enabled each time a system file needs to be altered (including '\ftp.cfg').
-

## 8. PROFINET Implementation

The option board implements PROFINET and PROFIdrive according to standard.

### 8.1 General

The A8NPRT\_2P PROFINET Option Board complies to PROFINET specification v2.2, conformance class B.

#### Performance:

- 100 Mbps, full duplex with auto-negotiation enabled as default
- Real Time (RT) communication, 2 ms cycle time

#### Device Model

- One IO Device instance
- Each IO Device instance includes one or more Application Processes represented by identifiers (API)
- API 0 (zero) and API 14848 (PROFIdrive API) are implemented
- Each API implements one or more slots
- Each Slot implements one or more subslots
- Each subslot may implement one or more Channels

#### Slots & Subslots

One slot available for a selection of telegram types. Each module contains a MAP (Module Access Point) and a PROFIdrive telegram submodule (standard or device specific).

### 8.2 Electronic Data Sheet (GSD)

A standard GSD file is available for download at the Mitsubishi Electric web site, see section "Download" on page 1.

### 8.3 Fast Start Up

The Fast Start Up function enables PROFINET IO devices, connected to the network, to power up quickly, this is useful in for example robot applications, where rapid retooling is necessary. This function has to be activated when configuring the option board.

### 8.4 DAP

A DAP (Device Access Point) is a module that is representative of the unit. The default DAP is compatible with PROFINET version 2 but there is an alternative DAP supplied for compatibility with older PROFINET versions (V1.5).

## **8.5 I&M**

Identification & Maintenance (I&M) provides a standard way of gathering information about an I/O device. The I&M information can be accessed by the IO Controller by means of acyclic Record Data Read/Write services.

The option board provides support for I&M 0-4 data.

## 9. Data Exchange

### 9.1 General Information

Inverter parameters can be accessed acyclically by means of the PROFIdrive Parameter Protocol. The master issues a parameter request to the option board. The option board processes the request. Meanwhile the master repeatedly tries to read the parameter response, but an error message will be returned until the request is fully processed by the module, after which the master can read the response.

#### Translation of signal numbers

Signal numbers used in the inverter do not directly translate to signal numbers (PNUs) used on PROFINET. An offset is added to avoid ambiguous numbering on PROFINET, where parameters and monitor data have different PNU numbers.

The array below presents a summary of the signal number translation. For a complete presentation of how to translate the signal numbers for the option board drive profile parameters, see "Translation of Signal Numbers" on page 123.

| Signal Type                           | Signal No, Inverter              |                 | Offset              | PNU No, PROFIdrive (Signal No. + Offset) | Acyclic Data Exchange | Cyclic Data Exchange |
|---------------------------------------|----------------------------------|-----------------|---------------------|--|-----------------------|----------------------|
|                                       | Hexadecimal                      | Decimal         |                     |  |                       |                      |
| Parameter                             | 0h...54Fh                        | 0 ... 1359d     | 5096d               | 5096d ... 6455d                          | Yes                   | No                   |
| Monitor Data                          | 000h ... 3FFh                    | 0d ... 1023d    | 9192d               | 9192d ... 10215d                         | Yes                   | Yes                  |
| Option Board Drive Profile Parameters | 400h ... 411h                    | 1024d ... 1041d | 13288d              | 14312d ... 14329d                        | Yes                   | Yes/no <sup>1</sup>  |
|                                       | 412h, 415h ... 41Ch <sup>2</sup> | 1042d,          | 13288d <sup>2</sup> | 14330d,                                  | Yes                   | No                   |
|                                       |                                  | 1045d ... 1052d |                     | 14333d ... 14340d                        |                       |                      |
|                                       |                                  |                 | 15336d <sup>2</sup> | 16378d,                                  | Yes                   | Yes                  |
|                                       |                                  | 413h ... 414h   | 1043d ... 1044d     | 13288d                                   | 14331d ... 14332d     | Yes                  |
|                                       | 41Dh ... 431h                    | 1053d ... 1073d | 13288d              | 14341d ... 14361d                        | Yes                   | Yes/no <sup>1</sup>  |

<sup>1</sup> Some of these parameters can be mapped for cyclic data exchange, see "Translation of Signal Numbers" on page 123.

<sup>2</sup> These parameters can either be accessed (as acyclic data) as an array, with offset 13288d, or can each entry in the array be mapped as a separate parameter with offset 15336d (as acyclic and/or cyclic data).

---

**Note:** The scaling of the parameter values are different if you use the parameter unit or the option board web pages, for further information, see "Parameter Data" on page 95.

---

## 9.2 Inverter parameters (Acyclic Data Exchange)

Inverter parameters are available only via acyclic communication. They **cannot** be used in cyclic data exchange, for example it is **not** possible to map them as parameters for telegram 102. The offset used for inverter parameters is 5096, i.e. inverter parameter no. 1 (maximum frequency) shall be addressed as PNU 5097. An example of reading/writing inverter parameters is shown in "Reading a parameter (Sequence 1)" on page 44.

All of the inverter parameters are unsigned 16bit integers, with the exception of the following:

| Parameter | PNU  | Description                                      | Data type               |
|-----------|------|--|-------------------------|
| 7         | 5103 | Acceleration time                                | Unsigned 32 bit integer |
| 8         | 5104 | Deceleration time                                |                         |
| 16        | 5112 | Jog acceleration/deceleration time               |                         |
| 44        | 5140 | Second acceleration/deceleration time            |                         |
| 110       | 5206 | Third acceleration/deceleration time             |                         |
| 111       | 5207 | Third deceleration time                          |                         |
| 264       | 5360 | Power-failure deceleration time 1                |                         |
| 265       | 5361 | Power-failure deceleration time 2                |                         |
| 791       | 5887 | Acceleration time in low-speed range             |                         |
| 792       | 5888 | Deceleration time in low-speed range             |                         |
| All other | -    | All inverter parameters NOT listed in this table |                         |

## 9.3 Monitor Data (Acyclic and Cyclic Data Exchange)

This chapter contains a table of monitor data available via both cyclic and acyclic data exchange. The values are available as 16 and 32 bit integers. To calculate the actual monitor data value, the returned integer should be multiplied by the unit specified for that parameter. For example if PNU 9193 (output frequency) is requested and a value of 500 is returned, this means that the output frequency is equal to 5 Hz ( $500 \times 0.01$  Hz).

| PNU No        | Internal No | Description                         | Unit           | Type     | Access type |
|---------------|-------------|-------------------------------------|----------------|----------|-------------|
| <b>16 bit</b> |             |                                     |                |          |             |
| 9193          | 1           | Output frequency                    | 0.01Hz         | unsigned | R           |
| 9194          | 2           | Output current                      | 0.01A/0.1A     | unsigned | R           |
| 9195          | 3           | Output voltage                      | 0.1V           | unsigned | R           |
| 9197          | 5           | Frequency setting value             | 0.01Hz         | unsigned | R           |
| 9198          | 6           | Motor speed                         | 1 rpm          | unsigned | R           |
| 9199          | 7           | Motor torque                        | 0.1%           | unsigned | R           |
| 9200          | 8           | Converter output voltage            | 0.1V           | unsigned | R           |
| 9201          | 9           | Regenerative brake duty             | 0.1%           | unsigned | R           |
| 9202          | 10          | Electric thermal relay function     | 0.1%           | unsigned | R           |
| 9203          | 11          | Output current peak value           | 0.01A/0.1A     | unsigned | R           |
| 9204          | 12          | Converter output voltage peak value | 0.1V           | unsigned | R           |
| 9205          | 13          | Input power                         | 0.01/<br>0.1kW | unsigned | R           |
| 9206          | 14          | Output power                        | 0.01/<br>0.1kW | unsigned | R           |
| 9207          | 15          | Input terminal status *1            | -              | -        | R           |
| 9208          | 16          | Output terminal status *2           | -              | -        | R           |

| PNU No        | Internal No | Description  | Unit       | Type     | Access type |
|---------------|-------------|--|------------|----------|-------------|
| <b>16 bit</b> |             |  |            |          |             |
| 9209          | 17          | Load meter   | 0.1%       | unsigned | R           |
| 9210          | 18          | Motor excitation current                                       | 0.01A/0.1A | unsigned | R           |
| 9211          | 19          | Position pulse   | 1          | unsigned | R/W         |
| 9212          | 20          | Cumulative energization time                                   | 1h         | unsigned | R           |
| 9214          | 22          | Orientation status   | 1          | unsigned | R           |
| 9215          | 23          | Actual operation time  | 1h         | unsigned | R           |
| 9216          | 24          | Motor load factor  | 0.1%       | unsigned | R           |
| 9217          | 25          | Cumulative power   | 1kWh       | unsigned | R           |
| 9218          | 26          | Position command (lower 16 bits)                               | 1          | signed   | R           |
| 9219          | 27          | Position command (upper 16 bits)                               | 1          | signed   | R           |
| 9220          | 28          | Current position (lower 16 bits)                               | 1          | signed   | R           |
| 9221          | 29          | Current position (upper 16 bits)                               | 1          | signed   | R           |
| 9222          | 30          | Droop pulse (lower 16 bits)                                    | 1          | signed   | R           |
| 9223          | 31          | Droop pulse (upper 16 bits)                                    | 1          | signed   | R           |
| 9224          | 32          | Torque order   | 0.1%       | unsigned | R           |
| 9225          | 33          | Torque current order   | 0.1%       | unsigned | R           |
| 9226          | 34          | Motor output   | 0.1kW      | unsigned | R           |
| 9227          | 35          | Feedback pulse   | 1          | unsigned | R           |
| 9230          | 38          | Trace status   | -          | unsigned | R           |
| 9232          | 40          | PLC function user monitor 1                                    | -          | unsigned | R           |
| 9233          | 41          | PLC function user monitor 2                                    | -          | unsigned | R           |
| 9234          | 42          | PLC function user monitor 3                                    | -          | unsigned | R           |
| 9238          | 46          | Motor temperature  |            |          | R           |
| 9242          | 50          | Power saving effect  | -          | unsigned | R           |
| 9243          | 51          | Cumulative saving power  | -          | unsigned | R           |
| 9244          | 52          | PID set point  | 0.1%       | unsigned | R/W         |
| 9245          | 53          | PID measured value   | 0.1%       | unsigned | R/W         |
| 9246          | 54          | PID deviation  | 0.1%       | unsigned | R/W         |
| 9250          | 58          | Option input terminal status1 *3                               | -          | -        | R           |
| 9251          | 59          | Option input terminal status2 *3                               | -          | -        | R           |
| 9252          | 60          | Option output terminal status *4                               | -          | -        | R           |
| 9253          | 61          | Motor thermal load factor                                      | 0.1%       | unsigned | R           |
| 9254          | 62          | Transistor thermal load factor                                 | 0.1%       | unsigned | R           |
| 9256          | 64          | PTC thermistor resistance                                      | ohm        | unsigned | R           |
| 9257          | 65          | Output power   |            |          | R           |
| 9192          |             | (with regenerative display)                                    |            |          |             |
| 9258          | 66          | Cumulative regenerative power                                  |            |          | R           |
| 9259          | 67          | PID measured value 2   | 0.1%       | unsigned | R           |
| 9260          | 68          | 2nd PID set point  | 0.1%       | unsigned | R/W         |
| 9261          | 69          | 2nd PID measured value   | 0.1%       | unsigned | R/W         |
| 9262          | 70          | 2nd PID deviation  | 0.1%       | unsigned | R/W         |
| 9263          | 71          | Cumulative pulse   | 1          | signed   | R           |
| 9264          | 72          | Cumulative pulse carrying-over times                           | 1          | signed   | R           |
| 9265          | 73          | Cumulative pulse (control terminal option)                     | 1          | signed   | R           |
| 9266          | 74          | Cumulative pulse carrying-over times (control option terminal) | 1          | signed   | R           |
| 9272          | 80          | Integrated power on time                                       |            |          | R           |
| 9273          | 81          | Running time   |            |          | R           |

| PNU No        | Internal No | Description                        | Unit            | Type     | Access type |
|---------------|-------------|------------------------------------|-----------------|----------|-------------|
| <b>16 bit</b> |             |                                    |                 |          |             |
| 9274          | 82          | Saving energy monitor              |                 |          | R           |
| 9276 - 9283   | 84 - 91     | Fault code (1) - (8)               | -               | -        | R           |
| 9287          | 95          | 2nd PID measured value 2           | 0.1%            | unsigned | R           |
| 9288          | 96          | 2nd PID manipulated value          | 0.1%            | signed   | R           |
| 9292          | 100         | Current position 2 (lower 16 bits) | 1               | signed   | R           |
| 9293          | 101         | Current position 2 (upper 16 bits) | 1               | signed   | R           |
| 9294          | 102         | PID manipulated value              | 0.1%            | signed   | R           |
| 9441          | 249         | Run command *5                     | -               | -        | R/W         |
| <b>32 bit</b> |             |                                    |                 |          |             |
| 9705          | 513         | Output frequency                   | 0.01Hz          | signed   | R           |
| 9707          | 515         | Setting frequency                  | 0.01Hz          | signed   | R           |
| 9709          | 517         | Motor rotation                     | 0.1rpm          | signed   | R           |
| 9711          | 519         | Load meter                         | 0.1%            | signed   | R           |
| 9713          | 521         | Current position 2                 | 1               | signed   | R/W         |
| 9715          | 523         | Watt-hour meter(1kWh step)         | 1kWh            | unsigned | R           |
| 9717          | 525         | Watt-hour meter(0.1/0.01kWh step)  | 0.1/<br>0.01kWh | unsigned | R           |
| 9719          | 527         | Position error                     | 1               | signed   | R           |
| 9721          | 529         | Position command                   | 1               | signed   | R           |
| 9723          | 531         | Current position                   | 1               | signed   | R           |

**\*1 Input terminal status details (ex. A800)**

|     |   |   |   |    |     |      |     |     |    |    |    |    |    |     |     |
|-----|---|---|---|----|-----|------|-----|-----|----|----|----|----|----|-----|-----|
| b15 |   |   |   |    |     |      |     |     |    |    |    |    |    | b0  |     |
| -   | - | - | - | CS | RES | STOP | MRS | JOG | RH | RM | RL | RT | AU | STR | STF |

This data indicates status of main unit input terminal.  
The number of terminal and names depends on main unit specification.

**\*2 Output terminal status details (ex. A800)**

|     |   |   |   |   |   |   |   |    |      |      |    |    |     |    |     |
|-----|---|---|---|---|---|---|---|----|------|------|----|----|-----|----|-----|
| b15 |   |   |   |   |   |   |   |    |      |      |    |    |     | b0 |     |
| -   | - | - | - | - | - | - | - | SO | ABC2 | ABC1 | FU | OL | IPF | SU | RUN |

This data indicates status of main unit output terminal.  
The number of terminal and names depends on main unit specification.

**\*3 Option input terminal status1,2 (ex. A800 and FR-A8AX)**

Option input terminal status1

|     |     |     |     |     |     |    |    |    |    |    |    |    |    |    |    |
|-----|-----|-----|-----|-----|-----|----|----|----|----|----|----|----|----|----|----|
| b15 |     |     |     |     |     |    |    |    |    |    |    |    |    | b0 |    |
| X15 | X14 | X13 | X12 | X11 | X10 | X9 | X8 | X7 | X6 | X5 | X4 | X3 | X2 | X1 | X0 |

Option input terminal status2

|     |   |   |   |   |   |   |   |   |   |   |   |   |   |    |    |
|-----|---|---|---|---|---|---|---|---|---|---|---|---|---|----|----|
| b15 |   |   |   |   |   |   |   |   |   |   |   |   |   | b0 |    |
| -   | - | - | - | - | - | - | - | - | - | - | - | - | - | -  | DY |

This data indicates status of FR-A8AX terminal.

**\*4 Option output terminal status (ex. A800 and A8AY/A8AR)**

|     |   |   |   |   |   |     |     |     |    |    |    |    |    |    |    |
|-----|---|---|---|---|---|-----|-----|-----|----|----|----|----|----|----|----|
| b15 |   |   |   |   |   |     |     |     |    |    |    |    |    | b0 |    |
| -   | - | - | - | - | - | RA3 | RA2 | RA1 | Y6 | Y5 | Y4 | Y3 | Y2 | Y1 | DY |

This data indicates status of FR-A8AY(Y0-Y6), FR-A8AR(RA1-RA3) terminal.

**\*5 Run command (ex. A800 and A8AY/A8AR)**

Users can specify the terminal function using this data.

|     |   |   |   |     |      |    |     |     |    |    |    |    |   |    |    |
|-----|---|---|---|-----|------|----|-----|-----|----|----|----|----|---|----|----|
| b15 |   |   |   |     |      |    |     |     |    |    |    |    |   | b0 |    |
| -   | - | - | - | RES | STOP | CS | JOG | MRS | RT | RH | RM | RL | - | -  | AU |

These bits function is depending on VFD parameter setting.

## 9.4 Drive Profile Parameters (Acyclic Data Exchange)

Inverter parameters are, when possible, mapped to PROFIdrive parameters. The remaining parameters can be accessed as vendor specific parameters.

It is recommended not to use the standard PROFIdrive parameters as vendor specific parameters.

### 9.4.1 PROFIdrive Parameters

The following parameters are implemented in the option board:

| Parameter | Definition                             | R/W | Data Type                  | Value/Description   |
|-----------|--|-----|----------------------------|---|
| P915      | Selection switch Setpoint telegram     | R   | Array [n]<br>Unsigned16    | Holds the current configuration of the Setpoint telegram.   |
| P916      | Selection switch Actual value telegram | R   | Array [n]<br>Unsigned16    | Holds the current configuration of the Actual value telegram.   |
| P922      | Telegram Selection                     | R   | Unsigned 16                | Default value: Standard telegram 1.<br>Reflects the latest accepted configuration data from the master.   |
| P923      | List of all parameters for signals     | R   | Array[60000]<br>Unsigned16 | All parameters that are possible to map to process data (i.e. is defined as PROFIdrive signals) are listed here; subindex = signal number.<br>If a parameter connected to the specific signal is possible to map, the PNU number is returned. If the parameter is not possible to map, 0 is returned. |
| P924      | Status word bit Pulses Enabled         | R   | Array[2]<br>Unsigned16     | Subindex 0: 2 (Signal number for ZSW1)<br>Subindex 1: 15 (Bit position)   |
| P930      | Operating mode                         | R/W | Unsigned16                 | 0001h: Speed control mode<br>8000h: Torque control mode<br>8001h: Vendor specific mode<br>Read from the application during initialization.  |
| P944      | Fault message counter                  | R   | Unsigned16                 | Incremented by one each time the fault buffer (P947) changes.   |
| P947      | Fault numbers                          | R   | Array[8]<br>Unsigned16     | Subindex 0: Active fault situation (if the drive is in Faulted state).<br>Subindex 1-7: Fault history, where subindex 1 holds the most recent fixed fault situation.<br>Fault number is the corresponding PROFIdrive fault class.   |
| P950      | Scaling of fault buffer                | R   | Array[2]<br>Unsigned16     | Subindex 0: 8<br>Subindex 1: 1<br>Defines the number of fault situations (subindex 0) and the number of fault messages (subindex 1) for each situation that the fault buffer can hold.  |
| P951      | Fault number list                      | R   | Array[255]<br>Unsigned16   | Holds descriptive text for each fault that is supported by the option board.<br>Each subindex corresponds to the event code number, which means that the accessible subindices are limited.<br>The fault description is accessed as an additional text array.   |

| Parameter | Definition            | R/W | Data Type              | Value/Description   |
|-----------|-----------------------|-----|------------------------|---|
| P964      | Device identification | R   | Array[5]<br>Unsigned16 | Manufacturer ID: 010Ch (HMS)<br>Drive Unit Type: 0<br>Version (software) xxyy (decimal)<br>Firmware date, year yyyy (decimal)<br>Firmware date, day/month ddm (decimal)   |
| P965      | Profile number        | R   | OctetString<br>2       | Byte 0: 3 (PROFIdrive profile)<br>Byte 1: 41 (Version 4.1)  |
| P967      | STW1                  | R   | V2                     | Last control word received from the controller.   |
| P968      | ZSW                   | R   | V2                     | Current status word from the drive.   |
| P972      | Drive reset           | R/W | Unsigned16             | 1: Power-on reset<br>2: Prepare power-on reset  |
| P980      | List of parameters    | R   | Array[n]<br>Unsigned16 | Parameter numbers of all existing parameters are saved in the subindices (profile parameters and regular drive parameters). The array is assigned in increasing sequence and consecutively. The end of the list of defined parameters is marked by a subindex with the value 0. |
| P61000    | Name of station       | R   | Octetstring<br>240     | The station name of the device.   |
| P61001    | IP address            | R   | Octetstring 4          | Current IP address  |
| P61002    | MAC address           | R   | Octetstring 6          | The MAC address   |
| P61003    | Gateway               | R   | Octetstring4           | Current gateway address   |
| P61004    | Subnet mask           | R   | Octetstring4           | Current subnet mask   |

#### 9.4.2 Setpoint- and Actual Value (P915/P916)

P915 and P916 reflect the configuration of the PROFINET telegrams that are used for process data. The parameters are read only and consist of arrays, where the number of elements corresponds to the number of words in the IO DATA. Each element holds the PNU (Parameter Number) of the parameter mapped to that particular IO DATA word.

The parameters reflect the latest accepted parameterization data.

#### 9.4.3 Signal List (P923)

The signal list is not saved. It is created at the time of request only for those elements (subindices) that are requested. The possibility to map vendor specific parameters is examined by asking for the Descriptor attribute of the specific parameter. It is not possible to map other PROFIdrive standard parameters than P967 and P968 (Control and Status words).


#### 9.4.4 Drive Reset (P972)

The PROFINET master can send a reset request to the application by writing to this parameter. If the request is rejected an error is returned.

| Error Code | Description   |
|------------|---|
| 0          | Illegal parameter number (Drive reset not supported). |
| 1          | Request cannot be executed due to operation status.   |
| 7          | Request cannot be executed due to operation status.   |

## 9.5 General State Diagram

This general state diagram shows how the inverter behaves based on Control Word 1 (STW1). For detailed state diagrams for various modes, please consult ProfiDrive technical specification manual.



### 9.5.1 Stopping the motor

While inverter is in operation state it can be stopped in different ways using control word 1 (STW1).

Quick stop results in motor decelerating to a stop with speed specified in inverter parameter 1103. This stop is achieved by disabling “no quick stop” bit (STW1 bit 2). After quick stop inverter transfers to “Switching ON inhibited” state.

Coast stop results in cutting power from motor and letting it coast to stop. This stop is achieved by disabling “no coast stop” bit (STW1 bit 1). After coast stop inverter transfers to “Switching ON inhibited” state.

Disabling “ON” bit (STW1 bit 0) will result in motor decelerating to stop according to inverter parameter 8. Inverter transfers to “Ready for Switching ON” state.

Disabling “Enable Operation” bit (STW1 bit 3) will result in motor coasting to stop, after stopping inverter transfers to “Switched ON” state.

## 9.6 Process Data (Cyclic Data Exchange)

### 9.6.1 General

Drive control is per default performed through the cyclic data exchange channel. DriveControl, Drive-Status, Setpoint and Actual Values are sent as IO DATA telegrams on PROFINET. These telegrams are transformed and mapped to the inverter parameters by the option board.

The Process Data map is based entirely on the requirements of PROFIdrive and the end user by means of User Parameterization Data. The active process data is mapped in the configuration tool, where PROFIdrive profile specific signals are specified using signal numbers 1-99 and vendor specific signals are specified using signal numbers 1001... 59999.

---

**Note:** The parameter numbers are different in the web pages than in the PROFINET configuration.

---

### 9.6.2 IO Device Structure

The only submodule carrying cyclic process data, is the Telegram Data submodule. Each IO DATA channel is assigned a signal, which in turn is mapped to an inverter parameter/monitor data.

### 9.6.3 Signals

Each IO DATA channel is assigned a signal which is mapped to an inverter parameter. Thus PROFIdrive parameters that are to be exchanged as IO DATA (i.e. Process Data) must be assigned a unique signal number.

Signal numbers 1...99 are reserved for standard PROFIdrive signals, while signals 1001 ... 59999 are used for vendor specific signals.

The table below shows the implementation of the PROFIdrive signal list.

| Signal       | Abbreviation | PROFIdrive Parameter  | Inverter Parameter                   |
|--------------|--------------|-----------------------|--------------------------------------|
| 1            | STW1         | Control word 1 (P967) | DriveControl                         |
| 2            | ZSW1         | Status word 1 (P968)  | DriveStatus                          |
| -            | -            | -                     | (not assigned)                       |
| 5            | NSOLL_A      | Speed setpoint A      | SetpointSpeed                        |
| 6            | NIST_A       | Speed actual value A  | ActualSpeed                          |
| -            | -            | -                     | (not assigned)                       |
| 1001...59999 | -            | Vendor specific       | Mapped to Process Data (if possible) |

Below is a brief explanation of the format of the used signals. For a detailed explanation, including control and status words specific to various operation modes, please consult ProfiDrive specification manual.

**Control Word STW1**

| Bit   | Contents                |
|-------|-------------------------|
| 0     | ON                      |
| 1     | No Coast Stop           |
| 2     | No Quick Stop           |
| 3     | Enable Operation        |
| 4     | Enable Ramp Generator   |
| 5     | Unfreeze Ramp Generator |
| 6     | Enable Setpoint         |
| 7     | Fault Acknowledge       |
| 8     | Jog 1 ON (not used)     |
| 9     | Jog 2 ON (not used)     |
| 10    | Control By PLC          |
| 11-15 | -                       |

**Status Word ZSW1**

| Bit   | Contents                     |
|-------|------------------------------|
| 0     | Ready To Switch ON           |
| 1     | Ready To Operate             |
| 2     | Operation Enabled            |
| 3     | Fault Present                |
| 4     | Coast Stop Not Activated     |
| 5     | Quick Stop Not Activated     |
| 6     | Switching On Inhibited       |
| 7     | Warning Present              |
| 8     | Speed Error Within Tolerance |
| 9     | Control Requested            |
| 10-14 | -                            |
| 15    | Pulses Enabled               |

**Speed setpoint A (NSOLL\_A)**

The output frequency set by NSOLL\_A is calculated relative to the rated frequency parameter (inverter parameter no. 3).

$$f = \frac{NSOLL\_A}{0x4000} \times f_r$$

$$NSOLL\_A = \frac{f_{out}}{f_{rated}} \times 16384$$

Forward 50Hz

| Device | F | E | D | C | B | A | 9 | 8 | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |       |
|--------|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|-------|
| D2000  | 0 | 0 | 0 | 0 | 0 | 1 | 0 | 0 | 0 | 0 | 0 | 0 | 1 | 1 | 1 | 1 | 1039  |
| D2001  | 0 | 1 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 16384 |

Reverse 50Hz

| Device | F | E | D | C | B | A | 9 | 8 | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |        |
|--------|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|--------|
| D2000  | 0 | 0 | 0 | 0 | 0 | 1 | 0 | 0 | 0 | 0 | 0 | 0 | 1 | 1 | 1 | 1 | 1039   |
| D2001  | 1 | 1 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | -16384 |

**Speed actual value A (NIST\_A)**

Speed actual value A is calculated in the same way as NSOLL\_A.

### 9.6.4 Telegram Types

The Option Board supports PROFIdrive Standard Telegram 1. If additional parameters are to be mapped to process data, one of the additional product-specific telegrams (100-103) must be used, depending on the size of the data in question.

| Telegram | Description                     | Size (words) |
|----------|---------------------------------|--------------|
| 1        | Standard Telegram 1             | 2            |
| 100      | Telegram 100 (Torque control)   | 2            |
| 101      | Telegram 101 (Position control) | 10           |
| 102      | Telegram 102 (Custom)           | 18           |
| 103      | Telegram 103 (Custom)           | 32           |

The user specifies which telegram to use when configuring the option board. Which telegram type is used, can be read using PROFIdrive parameter P922

---

**Note:** Only one telegram module can be used at a time.

---

#### Setpoint Telegram

Setpoint telegrams are used for data from the master to the inverter. Depending on control mode, the contents of the telegram may differ, see table below for configuration.

| Telegram   | IO DATA (PROFIdrive) |             | Read Process Data (Inverter) |  |
|--|----------------------|-------------|------------------------------|--|
|  | Word                 | Signal      | Octet                        | Process data Parameter                 |
| Speed Control (SC)<br>Torque Control (TC)<br>Position Control (PC) | IO DATA 1            | 1 (STW1)    | 0...1                        | DriveControl (0402h)                   |
| Speed Control (SC)<br>Torque Control (TC)<br>Position Control (PC) | IO DATA 2            | 5 (NSOLL_A) | 2...3                        | SetPoint Speed (0405h)                 |
|  |                      | 14349       |                              | TargetTorque (0425h)                   |
|  |                      | 9441        |                              | Run command (00F9h)                    |
| Position Control (PC)  | IO DATA 3            | 9713        | 4...7                        | PositionReference (0209h...020Ah)      |
| Position Control (PC)  | IO DATA 4            |             |                              |  |
| Position Control (PC)  | IO DATA 5            | 5 (NSOLL_A) | 8...9                        | SetPointSpeed (0405h)                  |
| Position Control (PC)  | IO DATA 6            | 16383       | 10...13                      | AccelerationDeltaTime (0417h...0418h)  |
| Position Control (PC)  | IO DATA 7            |             |                              |  |
| Position Control (PC)  | IO DATA 8            | 16387       | 14...17                      | DecelerationDelta Time (014Bh...041Ch) |
| Position Control (PC)  | IO DATA 9            |             |                              |  |

**Actual Value Telegram**

Actual value telegrams are used for data from the inverter to the master. Depending on control mode, the contents of the telegram may differ, see table below for configuration.


| Telegram   | IO DATA (PROFIdrive) |            | Write Process Data (Inverter) |                                |
|--|----------------------|------------|-------------------------------|--------------------------------|
|  | Word                 | Signal     | Octet                         | Process data Parameter         |
| Speed Control (SC)<br>Torque Control (TC)<br>Position Control (PC) | IO DATA 1            | 2 (ZSW1)   | 0...1                         | DriveStatus (0403h...0404h)    |
| Speed Control (SC)<br>Torque Control (TC)<br>Position Control (PC) | IO DATA 2            | 6 (NIST_A) | 2...3                         | ActualSpeed (0407h)            |
|  |                      | 14350      |                               | ActualTorque (0426h)           |
|  |                      | 9208       |                               | Output terminal (0010h)        |
| Position Control (PC)  | IO DATA 3            | 9713       | 4...7                         | ActualPosition (0209h...020Ah) |
| Position Control (PC)  | IO DATA 4            |            |                               |                                |
| Position Control (PC)  | IO DATA 5            | 6 (NIST_A) | 8...9                         | ActualSpeed (0407h)            |
| Position Control (PC)  | IO DATA 6            | 14250      | 10...11                       | ActualTorque (0426h)           |
| Position Control (PC)  | IO DATA 7            |            |                               |                                |
| Position Control (PC)  | IO DATA 8            | (9719)     | 12...15                       | PositionError (020Fh...0210h)  |
| Position Control (PC)  | IO DATA 9            |            |                               |                                |

## 9.7 Acyclic Data Exchange

This subchapter describes some of the basic sequences used in acyclic communication. All available sequences are described in the ProfiDrive Specification manual (chapter 6.2.3.6 Telegram sequences for Parameter Access).

Acyclic communication is available via the ProfiDRIVE API (0x3a00), slot no. 1, sub-slot no. 1, index 47.

The data flow for acyclic communication always consists of writing of the parameter request, and reading the parameter response. The parameter response read may fail, if the data requested is not yet ready. The option card should be asked for a response again, until it is ready. This is presented on the figure below:



### 9.7.1 Explanation of fields used in requests

This table explains the fields used in various sequences. Words sent in requests should have their most significant byte transmitted first (Big endian encoding). This is also the format in which incoming words will be transmitted.

| Field             | Data Type  | Values   | Comment                    |
|-------------------|------------|--|----------------------------|
| Request reference | Unsigned8  | 0x01 – 0xFF  |                            |
| Request ID        | Unsigned8  | 0x01 Request parameter<br>0x02 Change parameter  |                            |
| Response ID       | Unsigned8  | 0x01 Request parameter (+)<br>0x02 Change parameter (+)<br>0x81 Request parameter (-)<br>0x82 Change parameter (-) |                            |
| Axis / DO-ID      | Unsigned8  | 0x01   |                            |
| No. of Parameters | Unsigned8  | 0x01 – 0x27 Quantity   |                            |
| Attribute         | Unsigned8  | 0x10 Value<br>0x20 Description<br>0x30 Text  |                            |
| No. of elements   | Unsigned8  | 0x01 – 0xEA Quantity   |                            |
| Parameter number  | Unsigned16 | 0x0001 – 0xFFFF  |                            |
| Subindex          | Unsigned16 | 0x0001 – 0xFFFF  |                            |
| Format            | Unsigned8  | 0x01 – 0x36 Data types<br>0x40 – 0x44 Data types   | See data format type table |
| No. of values     | Unsigned8  | 0x00 – 0xEA Quantity   |                            |
| Error number      | Unsigned16 | 0x0000 – 0x00FF Error numbers  | See error table            |

### 9.7.2 Data format type table

| Data type     | Value |
|---------------|-------|
| BOOLEAN       | 0x01  |
| INTEGER8      | 0x02  |
| INTEGER16     | 0x03  |
| INTEGER32     | 0x04  |
| UINTEGER8     | 0x05  |
| UINTEGER16    | 0x06  |
| UINTEGER32    | 0x07  |
| VISIBLESTRING | 0x09  |
| OCTETSTRING   | 0x0a  |
| ZERO          | 0x40  |
| ERROR         | 0x44  |
| N2            | 0x71  |
| N4            | 0x72  |
| V2            | 0x73  |

### 9.7.3 Error table

| Error description                                     | Value |
|---|-------|
| IMPERMISSIBLE_PARAMETER_NUMBER                        | 0x00  |
| PARAMETER_VALUE_CANNOT_BE_CHANGED                     | 0x01  |
| LOW_OR_HIGH_LIMIT_EXCEEDED                            | 0x02  |
| FAULTY_SUBINDEX                                       | 0x03  |
| NO_ARRAY  | 0x04  |
| INCORRECT_DATA_TYPE                                   | 0x05  |
| SETTING_NOT_PERMITTED                                 | 0x06  |
| DESCRIPTION_ELEMENT_CANNOT_BE_CHANGED                 | 0x07  |
| NO_DESCRIPTION_DATA_AVAILABLE                         | 0x09  |
| NO_OPERATION_PRIORITY                                 | 0x0b  |
| NO_TEXT_ARRAY_AVAILABLE                               | 0x0f  |
| REQUEST_CANNOT_BE_EXECUTED_BECAUSE_OF_OPERATING_STATE | 0x11  |
| VALUE_IMPERMISSIBLE                                   | 0x14  |
| RESPONSE_TOO_LONG                                     | 0x15  |
| PARAMETER_ADDRESS_IMPERMISSIBLE                       | 0x16  |
| ILLEGAL_FORMAT  | 0x17  |
| NUMBER_OF_VALUES_ARE_NOT_CONSISTENT                   | 0x18  |
| AXIS_DO_NONEXISTENT                                   | 0x19  |
| PARAMETER_TEXT_ELEMENT_CANNOT_BE_CHANGED              | 0x20  |

### 9.7.4 Sequence 1: Request parameter value, single

| Byte no. | Field                                |
|----------|--------------------------------------|
| 0        | Request ID                           |
| 1        | Request reference                    |
| 2        | No. of parameters                    |
| 3        | DO-ID                                |
| 4        | No. of elements                      |
| 5        | Attribute value                      |
| 6-7      | Parameter number                     |
| 8-9      | Subindex (irrelevant for non-arrays) |

### 9.7.5 Sequence 1: Parameter response positive

| Byte no. | Field                                  |
|----------|--|
| 0        | Request ID                             |
| 1        | Request reference                      |
| 2        | No. of parameters                      |
| 3        | DO-ID                                  |
| 4        | No. of values                          |
| 5        | Format                                 |
| 6-7      | Parameter value                        |
| 8-9      | Parameter value (only for 32 bit data) |

**9.7.6 Sequence 1: Parameter response negative**

| Byte no. | Field             |
|----------|-------------------|
| 0        | Request ID        |
| 1        | Request reference |
| 2        | No. of parameters |
| 3        | DO-ID             |
| 4        | No. of values     |
| 5        | Format            |
| 6-7      | Error value       |

**9.7.7 Sequence 2: Change parameter value**

| Byte no. | Field                                |
|----------|--------------------------------------|
| 0        | Request ID                           |
| 1        | Request reference                    |
| 2        | No. of parameters                    |
| 3        | DO-ID                                |
| 4        | No. of elements                      |
| 5        | Attribute value                      |
| 6-7      | Parameter number                     |
| 8-9      | Subindex (irrelevant for non-arrays) |
| 10       | No. of values                        |
| 11       | Format                               |
| 12-13    | Set value                            |

**9.7.8 Sequence 2: Parameter response positive**

| Byte no. | Field             |
|----------|-------------------|
| 0        | Request ID        |
| 1        | Request reference |
| 2        | No. of parameters |
| 3        | DO-ID             |

**9.7.9 Sequence 2: Parameter response negative**

| Byte no. | Field             |
|----------|-------------------|
| 0        | Request ID        |
| 1        | Request reference |
| 2        | No. of parameters |
| 3        | DO-ID             |
| 4        | No. of values     |
| 5        | Format            |
| 6-7      | Error value       |

**9.7.10 Sequence 3: Request parameter value, several array elements**

| Byte no. | Field               |
|----------|---------------------|
| 0        | Request ID          |
| 1        | Request reference   |
| 2        | No. of parameters   |
| 3        | DO-ID               |
| 4        | No. of elements (n) |
| 5        | Attribute value     |
| 6-7      | Parameter number    |
| 8-9      | Subindex            |

**9.7.11 Sequence 3: Parameter response positive**

| Byte no.        | Field             |
|-----------------|-------------------|
| 0               | Request ID        |
| 1               | Request reference |
| 2               | No. of parameters |
| 3               | DO-ID             |
| 4               | No. of values     |
| 5               | Format            |
| 6-7             | Parameter value 1 |
| 8-9             | Parameter value 2 |
| ...             | ...               |
| (4+2n) – (5+2n) | Parameter value n |

**9.7.12 Sequence 3: Parameter response negative**

| Byte no. | Field             |
|----------|-------------------|
| 0        | Request ID        |
| 1        | Request reference |
| 2        | No. of parameters |
| 3        | DO-ID             |
| 4        | No. of values     |
| 5        | Format            |
| 6-7      | Error value       |



## 10. Diagnostics

Conversion of diagnostic fault codes

| Inverter Fault Code | Inverter Fault Name | Inverter Description | PROFIdrive Fault                     | PROFIdrive Fault Code |
|---------------------|---------------------|----------------------|--------------------------------------|-----------------------|
| 10h                 | E.OC1               | OC During Acc        | Motor Overload                       | 08                    |
| 11h                 | E.OC2               | Steady spd OC        | Motor Overload                       | 08                    |
| 12h                 | E.OC3               | OC During Dec        | Motor Overload                       | 08                    |
| 20h                 | E.OV1               | OV During Acc        | DC Link Overvoltage                  | 04                    |
| 21h                 | E.OV2               | Steady spd OV        | DC Link Overvoltage                  | 04                    |
| 22h                 | E.OV3               | OV During Dec        | DC Link Overvoltage                  | 04                    |
| 30h                 | E.THT               | Inv. Ovrload         | Overtemperature Electronic Device    | 06                    |
| 31h                 | E.THM               | Motor Ovrload        | Motor Overload                       | 08                    |
| 40h                 | E.FIN               | H/Sink O/Temp        | Overtemperature Electronic Device    | 06                    |
| 50h                 | E.IPF               | Inst. Pwr. Loss      | Mains Supply                         | 02                    |
| 52h                 | E.ILF               | Input phase loss     | Mains Supply                         | 02                    |
| 60h                 | E.OLT               | Stall Prev STP       | Motor Overload                       | 08                    |
| 70h                 | E.BE                | Br. Cct. Fault       | Brake Resistor                       | 14                    |
| 80h                 | E.GF                | Ground Fault         | Earth/Ground Fault                   | 07                    |
| 81h                 | E.LF                | Output phase loss    | Power Electronics                    | 05                    |
| 90h                 | E.OHT               | OH Fault             | Motor Overload                       | 08                    |
| 91h                 | E.PTC               | PTC Activated        | External                             | 16                    |
| A0h                 | E.OPT               | Option fault         | Engineering                          | 18                    |
| A1h                 | E.OP1               | Option1 fault        | Internal Communication               | 12                    |
| A2h                 | E.OP2               | Option2 fault        | Internal Communication               | 12                    |
| A3h                 | E.OP3               | Option3 fault        | Internal Communication               | 12                    |
| B0h                 | E.PE                | Corrupt memory       | Microcontroller Hardware or Software | 01                    |
| B1h                 | E.PUE               | PU Leave out         | Internal Communication               | 12                    |
| B2h                 | E.RET               | Retry No Over        | Technology                           | 17                    |
| B3h                 | E.PE2               | PR Storage Alarm     | Microcontroller Hardware or Software | 01                    |
| C0h                 | E.CPU               | CPU Fault            | Microcontroller Hardware or Software | 01                    |
| C1h                 | E.CTE               | PU Short cct         | Other                                | 19                    |
| C2h                 | E.P24               | 24VDC short cct      | Other                                | 19                    |
| C4h                 | E.CDO               | OC Detect level      | Technology                           | 17                    |
| C5h                 | E.IOH               | Inrush overheat      | Mains Supply                         | 02                    |
| C6h                 | E.SER               | VFD Comm error       | Internal Communication               | 12                    |
| C7h                 | E.AIE               | Analog in error      | External                             | 16                    |
| C8h                 | E.USB               | USB Comm error       | Internal Communication               | 12                    |
| C9h                 | E.SAF               | Safety cct fault     | Technology                           | 17                    |
| D0h                 | E.OS                | Overspeed            | Technology                           | 17                    |
| D1h                 | E.OSD               | Excess spd deviation | Technology                           | 17                    |
| D2h                 | E.ECT               | Enc. Signal loss     | Feedback                             | 11                    |
| D3h                 | E.OD                | Excess pos fault     | Technology                           | 17                    |
| D5h                 | E.MB1               | Brake seq fault      | Other                                | 19                    |
| D6h                 | E.MB2               | Brake seq fault      | Other                                | 19                    |
| D7h                 | E.MB3               | Brake seq fault      | Other                                | 19                    |
| D8h                 | E.MB4               | Brake seq fault      | Other                                | 19                    |

---

| <b>Inverter Fault Code</b> | <b>Inverter Fault Name</b> | <b>Inverter Description</b> | <b>PROFIdrive Fault</b>              | <b>PROFIdrive Fault Code</b> |
|----------------------------|----------------------------|-----------------------------|--------------------------------------|------------------------------|
| D9h                        | E.MB5                      | Brake seq fault             | Other                                | 19                           |
| DAh                        | E.MB6                      | Brake seq fault             | Other                                | 19                           |
| DBh                        | E.MB7                      | Brake seq fault             | Other                                | 19                           |
| DCh                        | E.EP                       | Enc. Phase Fault            | Feedback                             | 11                           |
| F1h                        | E.1                        | Fault 1 (opt slot 1)        | Internal Communication               | 12                           |
| F2h                        | E.2                        | Fault 2 (opt slot 2)        | Internal Communication               | 12                           |
| F3h                        | E.3                        | Fault 3 (opt slot 3)        | Internal Communication               | 12                           |
| F5h                        | E.5                        | Fault 5                     | Microcontroller Hardware or Software | 01                           |
| F6h                        | E.6                        | Fault 6                     | Microcontroller Hardware or Software | 01                           |
| F7h                        | E.7                        | Fault 7                     | Microcontroller Hardware or Software | 01                           |
| FBh                        | E.11                       | Fault 11                    | Technology                           | 17                           |
| FDh                        | E.13                       | Fault 13                    | Power Electronics                    | 05                           |
| 51h                        | E.UVT                      | Under Voltage               | Mains Supply                         | 02                           |

## A. Translation of Signal Numbers

Signal numbers used in the inverter do not directly translate to signal numbers (PNUs) used on PROFINET. An offset is added to avoid ambiguous numbering on PROFINET, where parameters and monitor data have different PNU numbers. Every signal number corresponds to 16 bits. A 32-bit parameter e.g., occupies two numbers, but is addressed by the lower number only.

| Name                                | Signal No, Inverter |         | Offset (decimal) | PNU No, PROFIdrive (Signal No. + Offset) | Acyclic Data Exchange | Cyclic Data Exchange |
|-------------------------------------|---------------------|---------|------------------|--|-----------------------|----------------------|
|                                     | Hexadecimal         | Decimal |                  |  |                       |                      |
| DriveControlMaskWrite               | 400                 | 1024    | 13288            | 14312                                    | Yes                   | Yes                  |
| DriveControl                        | 402                 | 1026    | 13288            | 14314                                    | Yes                   | Yes                  |
| DriveStatus                         | 403                 | 1027    | 13288            | 14315                                    | Yes                   | Yes                  |
| SetpointSpeed                       | 405                 | 1029    | 13288            | 14317                                    | Yes                   | Yes                  |
| CommandSpeed                        | 406                 | 1030    | 13288            | 14318                                    | Yes                   | Yes                  |
| ActualSpeed                         | 407                 | 1031    | 13288            | 14319                                    | Yes                   | Yes                  |
| SpeedScaleNumerator                 | 408                 | 1032    | 13288            | 14320                                    | Yes                   | No                   |
| SpeedScaleDenominator               | 40A                 | 1034    | 13288            | 1  | Yes                   | No                   |
| RatedSpeed                          | 40C                 | 1036    | 13288            | 14324                                    | Yes                   | No                   |
| PoleCount                           | 40D                 | 1037    | 13288            | 14325                                    | Yes                   | No                   |
| RatedCurrent                        | 40E                 | 1038    | 13288            | 14326                                    | Yes                   | No                   |
| RatedVoltage                        | 410                 | 1040    | 13288            | 14328                                    | Yes                   | No                   |
| MotorType                           | 411                 | 1041    | 13288            | 14329                                    | Yes                   | No                   |
| DriveMode <sup>2</sup>              |                     |         | 13288            | 14330                                    | Yes                   | No                   |
|                                     |                     |         | 15336            | 16378                                    | Yes                   | Yes                  |
| SupportedModes                      | 413                 | 1043    | 13288            | 14331                                    | Yes                   | No                   |
| AccelerationDeltaSpeed <sup>2</sup> |                     |         | 13288            | 14333                                    | Yes                   | No                   |
|                                     |                     |         | 15336            | 16381                                    | Yes                   | Yes                  |
| AccelerationDeltaTime <sup>2</sup>  |                     |         | 13288            | 1  | Yes                   | No                   |
|                                     |                     |         | 15336            | 16383                                    | Yes                   | Yes                  |
| DecelerationDeltaSpeed <sup>2</sup> |                     |         | 13288            | 14337                                    | Yes                   | No                   |
|                                     |                     |         | 15336            | 16385                                    | Yes                   | Yes                  |
| DecelerationDeltaTime <sup>2</sup>  | 41B                 | 1051    | 13288            | 1  | Yes                   | No                   |
|                                     |                     |         | 15336            | 16387                                    | Yes                   | Yes                  |
| QuickDecelerationDeltaSpeed         | 41D                 | 1053    | 13288            | 14341                                    | Yes                   | No                   |
| QuickDecelerationDeltaTime          | 41F                 | 1055    | 13288            | 1  | Yes                   | No                   |
| MaxSpeed                            | 421                 | 1057    | 13288            | 14345                                    | Yes                   | No                   |
| MinSpeed                            | 423                 | 1059    | 13288            | 14347                                    | Yes                   | No                   |
| TargetTorque                        | 425                 | 1061    | 13288            | 14349                                    | Yes                   | Yes                  |
| ActualTorque                        | 426                 | 1062    | 13288            | 14350                                    | Yes                   | Yes                  |
| TorqueSlope                         | 427                 | 1063    | 13288            | 14351                                    | Yes                   | No                   |
| TorqueProfileType                   | 429                 | 1065    | 13288            | 14353                                    | Yes                   | No                   |
| RatedTorque                         | 42A                 | 1066    | 13288            | 14354                                    | Yes                   | No                   |
| TorqueScaleNumerator                | 42C                 | 1068    | 13288            | 14356                                    | Yes                   | No                   |
| TorqueScaleDenominator              | 42E                 | 1070    | 13288            | 1  | Yes                   | No                   |
| DisableOptionCode                   | 430                 | 1072    | 13288            | 14360                                    | Yes                   | No                   |
| ShutdownOptionCode                  | 431                 | 1073    | 13288            | 14361                                    | Yes                   | No                   |

<sup>1</sup> On the network, this inverter parameter is presented as subindex 1 of the preceding parameter.

<sup>2</sup> These parameters can either be accessed (as acyclic data) as an array, with offset 13288d, or can each entry in the array be mapped as a separate parameter with offset 15336d (as acyclic and/or cyclic data).





## B. Troubleshooting

When a fault occurs where the inverter trips itself and the A8NPRT\_2P PROFINET Option Board, check the inverter's operation panel and the LED indications on the A8NPRT\_2P unit. Consult the checkpoints in the table below to identify the cause, and take appropriate countermeasures.

| Operation Panel Display on the Drive | LED indications on A8NPRT_2P Option board | Possible Cause   |  | Checkpoint/Troubleshooting   |
|--------------------------------------|---|--|--|--|
| 0.00E                                | No LED lit                                | The option board is not working.   | The option board is not mounted properly   | Check if the option board is mounted properly and in the correct option slot   |
|                                      |   |  | A firmware upgrade procedure was interrupted   | Contact your local Mitsubishi Electric representative for further assistance   |
|                                      |   | -  | Reset the inverter<br>Perform all parameter clear to initialize all parameter settings, then powercycle the inverter |  |
|                                      |   | The option board is busy   | A firmware upgrade procedure is currently running  | All LEDs are off during the last 10-15 seconds of a firmware upgrade. Follow the instructions appended to the firmware upgrade package                                 |
|                                      | LEDs lit                                  | Please refer to "LED Indicators" on page 13.   |  |  |
| E.OP1                                | MS and NS LEDs flashing green             | PROFINET master transitioned to STOP mode while "Control by PLC" (STW1 bit 10) was set, causing an inverter stop |  | In your application, clear bit 10 before transitioning to STOP mode or remove the cause that disconnects the data transmission between the master and the option board |
|                                      | MS LED green, NS LED off                  | Connection was closed while "Control by PLC" (STW1 bit 10) was set, causing an inverter stop                     | PROFINET master or network component was powered off   | Verify that the PROFINET master and all network components between master and option board are powered and fully functioning   |
|                                      |   |  | The network cables are not connected properly  | Check if the network cables are connected properly between all nodes of the network  |

## B.1 Windows Firewall Settings

In case of using a USB Ethernet adapter, the adapter will be recognized from windows as unidentified network, which is automatically a public or guest network. The windows firewall has two entries for inbound connections in the Mitsubishi m2mDriverlauncher. To make the Online Action work the entry for UDP connections (first entry) must be enabled for public networks as shown below.



## C. HICP (Host IP Configuration Protocol)

### C.1 General

The option board supports the HICP protocol used by the Anybus IPconfig utility for changing settings, e.g. IP address, Subnet mask, and enable/disable DHCP. Anybus IPconfig can be downloaded free of charge from the HMS website, [www.anybus.com](http://www.anybus.com). This utility may be used to access the network settings of any Anybus product connected to the network via UDP port 3250.

### C.2 Operation

Upon starting the program, the network is scanned for Anybus products. The network can be re-scanned at any time by clicking 'Scan'.

To alter the network settings of the option board, double-click on its entry in the list. A window will appear, containing the settings for the option board.

Validate the new settings by clicking 'Set', or click 'Cancel' to cancel all changes.

The screenshot shows a configuration window titled "Configure: 00-00-BC-20-50-02". It is divided into two main sections: "Ethernet configuration" and "DHCP".

**Ethernet configuration:**

- IP address: 10 . 10 . 12 . 246
- Subnet mask: 255 . 255 . 255 . 0
- Default gateway: 0 . 0 . 0 . 0
- Primary DNS: 0 . 0 . 0 . 0
- Secondary DNS: 0 . 0 . 0 . 0
- Hostname: homer
- Password: (empty field)
- New password: (empty field)

**DHCP:**

- Radio buttons for "On" and "Off". "Off" is selected.
- Checkbox for "Change password" is unchecked.

At the bottom of the window are two buttons: "Set" and "Cancel".

Optionally, the configuration can be protected from unauthorized access by a password. To enter a password, click on the 'Change password' checkbox, and enter the password under 'New password'.



# D. Copyright Notices

This product includes software developed by Carnegie Mellon, the Massachusetts Institute of Technology, the University of California, and RSA Data Security:

\*\*\*\*\*

Copyright 1986 by Carnegie Mellon.

\*\*\*\*\*

Copyright 1983,1984,1985 by the Massachusetts Institute of Technology

\*\*\*\*\*

Copyright (c) 1988 Stephen Deering.

Copyright (c) 1982, 1985, 1986, 1992, 1993

The Regents of the University of California. All rights reserved.

This code is derived from software contributed to Berkeley by Stephen Deering of Stanford University.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- Neither the name of the University nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE REGENTS AND CONTRIBUTORS ``AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE REGENTS OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

\*\*\*\*\*

Copyright (C) 1990-2, RSA Data Security, Inc. All rights reserved.

License to copy and use this software is granted provided that it is identified as the "RSA Data Security, Inc. MD4 Message-Digest Algorithm" in all material mentioning or referencing this software or this function.

License is also granted to make and use derivative works provided that such works are identified as "derived from the RSA Data Security, Inc. MD4 Message-Digest Algorithm" in all material mentioning or referencing the derived work.

RSA Data Security, Inc. makes no representations concerning either the merchantability of this software or the suitability of this software for any particular purpose. It is provided "as is" without express or implied warranty of any kind.

These notices must be retained in any copies of any part of this documentation and/or software.

\*\*\*\*\*

Copyright (C) 1991-2, RSA Data Security, Inc. Created 1991. All rights reserved.

License to copy and use this software is granted provided that it is identified as the "RSA Data Security, Inc. MD5 Message-Digest Algorithm" in all material mentioning or referencing this software or this function.

License is also granted to make and use derivative works provided that such works are identified as "derived from the RSA Data Security, Inc. MD5 Message-Digest Algorithm" in all material mentioning or referencing the derived work.

RSA Data Security, Inc. makes no representations concerning either the merchantability of this software or the suitability of this software for any particular purpose. It is provided "as is" without express or implied warranty of any kind.

These notices must be retained in any copies of any part of this documentation and/or software.

# Index

| <b>A</b>  | <b>M</b>                                      |
|---|---|
| Acyclic Data Exchange ..... 115                   | Monitor Data ..... 104                        |
| <b>C</b>  | <b>N</b>                                      |
| Control Word STW1 ..... 112                       | Network Connector ..... 12                    |
| <b>D</b>  | <b>O</b>                                      |
| Data Exchange ..... 103                           | Option Board Parameters ..... 86              |
| Drive Profile Parameters ..... 103                |   |
| Monitor Data ..... 103                            |   |
| Parameter ..... 103                               |   |
| Drive Profile Parameters ..... 108                |   |
| Drive Reset ..... 109                             |   |
| <b>E</b>  | <b>P</b>                                      |
| Environment                                       | Parameters                                    |
| Specifications ..... 8                            | 1300 (General settings) ..... 86              |
| Ethernet  | 1301 (Ethernet Host Settings) ..... 87        |
| Communication Settings (Parameter 1317) ... 88    | 1305 - 1308 (IP Address) ..... 87             |
| Host Settings (Parameter 1301) ..... 87           | 1309 - 1312 (Subnet Mask) ..... 87            |
|   | 1313 - 1316 (Gateway Address) ..... 87        |
|   | 1317 (Ethernet Communication Settings) ... 88 |
|   | Process Data ..... 111                        |
|   | PROFIdrive Parameters ..... 108               |
|   | Profinet Controller setup ..... 16            |
| <b>F</b>  | <b>S</b>                                      |
| FTP Server ..... 99                               | SIMATIC STEP7 ..... 76                        |
| <b>G</b>  | Specifications                                |
| Gateway Address (Parameters 1313 - 1316) ..... 87 | Environment ..... 8                           |
| General settings (Parameter 1300) ..... 86        | Speed actual value A (NIST_A) ..... 112       |
| General State Diagram ..... 110                   | Speed setpoint A (NSOLL_A) ..... 112          |
| GX Works2   | Status Word ZSW1 ..... 112                    |
| Network Detect ..... 53                           | Subnet Mask (Parameters 1309 - 1312) ..... 87 |
| Telegram 1 ..... 39                               |   |
| Telegram 102 ..... 41                             |   |
| <b>I</b>  | <b>T</b>                                      |
| Inverter parameters ..... 104                     | Telegram Types ..... 113                      |
| IP Address (Parameters 1305 - 1308) ..... 87      | TIA Portal                                    |
| <b>L</b>  | Acyclic communication ..... 65                |
| LED Indicators ..... 13                           | Telegram 1 ..... 54                           |
| Error ..... 13                                    | Telegram 102 ..... 63                         |
| Link (1, 2) ..... 13                              |   |
| Module status ..... 13                            |   |
| Network status ..... 13                           |   |
| <b>L</b>  | <b>W</b>                                      |
|   | Web Server ..... 91                           |

