

Programmable Controller

MELSEC  series

MR-JE-C Mapping Change Function Block Reference

CONTENTS

| | |
|---|-----------|
| CHAPTER 1 OVERVIEW | 2 |
| 1.1 Introduction | 2 |
| 1.2 Applicable Hardware and Software | 2 |
| 1.3 System Configuration Example | 2 |
| 1.4 Relevant Manuals | 2 |
| 1.5 Notes | 2 |
| CHAPTER 2 FUNCTION DESCRIPTION | 4 |
| 2.1 Sample Program | 4 |
| 2.2 Sample Program Processing | 4 |
| 2.3 Sample Program Configuration | 4 |
| 2.4 Mapping Change in Sample Program | 5 |
| 2.5 Program Execution Procedure | 5 |
| 2.6 Program Details | 6 |
| Servo amplifier mapping data reading program (Sample/ReadMap) | 6 |
| Servo amplifier mapping data changing program (Sample/ChangeMap) | 9 |
| Servo amplifier object reading/writing program (Sample/ServoObjectRW) | 11 |
| CHAPTER 3 FB LIBRARY | 13 |
| 3.1 Function Overview of the FB Library | 13 |
| List of FBs | 13 |
| Restrictions and precautions for all FBs | 13 |
| 3.2 Details of the FB Library | 14 |
| SVFB_ReadObject (Object reading) | 14 |
| SVFB_WriteObject (Object writing) | 16 |
| SVFB_ReadMultiObject (Reading multiple objects) | 18 |
| SVFB_WriteMultiObject (Writing multiple objects) | 20 |
| 3.3 List of Structures | 22 |
| Structure | 22 |
| 3.4 Troubleshooting | 23 |
| List of error codes | 23 |
| INSTRUCTION INDEX | 25 |
| REVISIONS | 27 |
| TRADEMARKS | 28 |

1 OVERVIEW

1.1 Introduction


This sample program is used to read/write objects of the servo amplifier MR-JE-C with SLMP.

With this program, data such as parameters can be read/written, and a mapping of link device responses message can be changed.

1.2 Applicable Hardware and Software

| Applicable Hardware and Software | Description |
|----------------------------------|---|
| CPU module | MELSEC-Q series CPU module Q**UDVCPU (First five digits of the serial No. are "18112" or later) |
| Slave unit | CC-Link IE Field Network Basic compatible MELSERVO-JE servo amplifier MR-JE-C |
| Engineering software | MELSOFT GX Works2 of version 1.560J or later |

1.3 System Configuration Example



1.4 Relevant Manuals

- MR-JE-_C SERVO AMPLIFIER INSTRUCTION MANUAL [SH030257]
- MR-JE-_C SERVO AMPLIFIER INSTRUCTION MANUAL (CC-Link IE Field Network Basic) [SH030256]
- MELSERVO-JE Servo amplifier INSTRUCTION MANUAL (TROUBLE SHOOTING) [SH030166]
- QCPU User's Manual (Hardware Design, Maintenance and Inspection) [SH080483]
- QnUCPU User's Manual (Function Explanation, Program Fundamentals) [SH080807]
- SLMP Reference Manual [SH080956]
- GX Works2 Version1 Operating Manual (Common) [SH080779]

1.5 Notes

This manual does not include the information on restrictions for using CPU modules and the combination.

Please read the user's manuals of the products before using them.

Please note the following and use the programs and FBs described in this manual.


- When using the FBs in an actual system, confirm that the FBs do not cause system control problems.
- Consider the points where interlock conditions are required in the system and insert interlock conditions.
- Mitsubishi Electric Corporation will not compensate any damages caused by the FBs.
- Contents may be deleted or changed without prior notice.

2 FUNCTION DESCRIPTION

2.1 Sample Program

This sample program changes the mapping of the servo amplifier MR-JE-C.
 The program uses the function blocks (FBs) for reading and writing objects of the servo amplifier.
 The sample program is a structured project.

2.2 Sample Program Processing



2.3 Sample Program Configuration

| File name | Description | Model | Engineering environment |
|---------------------|-----------------|----------|-------------------------|
| ChangeMapping_Q.gxw | FBD, ST program | QnUDVCPU | MELSOFT GX Works2 |

List of programs

| Program name | Description | Execution type | Description method |
|----------------------|---------------------------------------|----------------|--------------------|
| Sample/ReadMap | Mapping data reading sample program | Scan | FBD |
| Sample/ChangeMap | Mapping changing sample program | Scan | FBD |
| Sample/ServoObjectRW | Object reading/writing sample program | Scan | FBD |

FB/FUN

| FB name | Description |
|-----------------------|---|
| SVFB_ReadObject | Reads an object of a servo amplifier. |
| SVFB_WriteObject | Writes an object of a servo amplifier. |
| SVFB_ReadMultiObject | Reads multiple objects of a servo amplifier. |
| SVFB_WriteMultiObject | Writes multiple objects of a servo amplifier. |

2.4 Mapping Change in Sample Program

This sample program adds the following items to the default mapping of the cyclic communication of the servo amplifier MR-JE-C and changes the mapping.

For details of the mapping and object data, refer to the MR-JE- C SERVO AMPLIFIER INSTRUCTION MANUAL.

| Servo amplifier → Master station (RWrn) | | | |
|---|-------|---|--|
| Device No. | Index | Name | Default/Additional |
| RWrn00 | 6061 | Control mode display | MR-JE-C default mapping |
| RWrn01 | — | — | |
| RWrn02 | 6041 | Control status | |
| RWrn03 | 6064 | Current position (command unit) | |
| RWrn04 | | | |
| RWrn05 | 606C | Current velocity | |
| RWrn06 | | | |
| RWrn07 | 60F4 | Droop pulse | |
| RWrn08 | | | |
| RWrn09 | 6077 | Current torque | |
| RWrn0A | 2D11 | Control output 1 | |
| RWrn0B | 2D12 | Control output 2 | |
| RWrn0C | 2D13 | Control output 3 | |
| RWrn0D | 2A42 | Alarm No. | |
| RWrn0E | 60B9 | Touch probe function status | |
| RWrn0F | 60BA | Touch probe 1 Position latched on the rising edge | |
| RWrn10 | | | |
| RWrn11 | 60BB | Touch probe 1 Position latched on the falling edge | |
| RWrn12 | | | |
| RWrn13 | 2C12 | Input device status 1 | |
| RWrn14 | | | |
| RWrn15 | 2B09 | Effective load ratio | Sample program additional mapping data |
| RWrn16 | 2B0A | Peak load ratio | |
| RWrn17 | 2B02 | Servo motor speed [r/min] | |
| RWrn18 | | | |
| RWrn19 | 2B0C | Position within one rotation | |
| RWwn1A | | | |
| RWwn1B | 2B0F | Bus voltage | |
| RWwn1C | 2B25 | Internal temperature of encoder | |
| RWwn1D | 2B2D | Module power consumption | |
| RWwn1E | 2B2E | Module total power consumption | |
| RWwn1F | | | |

2.5 Program Execution Procedure

1. Double-click the sample project "ChangeMapping_Q.gxw" and launch the programming tool.
2. Change the model settings according to the CPU type used.
3. Write all the sample data to the CPU module.
4. After writing the data, reset the CPU module.
5. Turn ON the execution command label in the sample program to execute the program.


2.6 Program Details

Servo amplifier mapping data reading program (Sample/ReadMap)

1. Set the device information.

The IP address and port number of the servo amplifier are set in the External device information structure (AmpInfo) when the operating status of the CPU module is switched from STOP to RUN. Change the number of resends and arrival monitoring time as needed.


Example) IP address: 192.168.3.1, port number: 5010 (fixed for MR-JE-C)




2. Set the object information.

The response message register object of the servo amplifier is set in the Object information structure (MapTable).

* The sample program initializes data of 26 objects.



The read data is stored in the data area of the table and initialized.




3. Read the mapping information.

The mapping information is read from the servo amplifier after the StartReadMap label is turned ON.

When the processing normally completes, the Done label turns ON.

* The sample program is designed to read data of 26 objects.




Servo amplifier mapping data changing program (Sample/ChangeMap)

1. Set the device information.

The IP address and port number of the servo amplifier are set in the External device information structure (AmpInfo) when the operating status of the CPU module is switched from STOP to RUN. Change the number of resends and arrival monitoring time as needed.


Example) IP address: 192.168.3.1, port number: 5010 (fixed for MR-JE-C)



2. Set the object information.

The response message register object of the servo amplifier is set in the Object information structure (MapTable).

* The sample program specifies data of 25 objects.




The start [0] and end [24] of the table set the number of components, and [1] to [23] set the mapping data.



3. Write the mapping information.

The mapping information of the servo amplifier is written after the StartChangeMap label is turned ON.

When the processing normally completes, the Done label turns ON.




Servo amplifier object reading/writing program (Sample/ ServoObjectRW)

1. Set the device information.

The IP address and port number of the servo amplifier are set in the External device information structure (ExtDevice) when the operating status of the CPU module is switched from STOP to RUN. Change the number of resends and arrival monitoring time as needed.

Example) IP address: 192.168.3.1, port number: 5010 (fixed for MR-JE-C)




2. Set the object information.

The object of the servo amplifier to be read is set in the Object information structure (ObjectInfo).

Example) When reading the maximum velocity command (607Fh: 0h)


The index number: 607F and the sub index number: 0 are set when the operating status of the CPU module is switched from STOP to RUN.

The size and data are not referred at reading.



3. Read the servo amplifier object.

The value of the specified object is read from the servo amplifier and is output to the ReadData label after the ExecuteRead label is turned ON.



4. Write the servo amplifier object.

The value of the specified object of the servo amplifier is changed after the ExecuteWrite label is turned ON.

Example) When changing the maximum velocity command (607Fh: 0h) to 1800.00 r/min

After the following values are set in the Object information structure (ObjectInfo), the ExecuteWrite label is turned ON.


Index number: 607Fh, sub index number: 0h, size: 4 (bytes), data: 1800

ObjectInfo.wIndex := H607F;

ObjectInfo.wSubIndex := H0;

ObjectInfo.wSize := 4;

ObjectInfo.wdData := 1800;



3 FB LIBRARY

3.1 Function Overview of the FB Library

List of FBs

The following table lists the FBs used in the MELSEC-Q series QnUDVCPUCPU module.

| Item | Description | Version |
|-----------------------|---|---------|
| SVFB_ReadObject | Reads an object of a servo amplifier. | 00A |
| SVFB_WriteObject | Writes an object of a servo amplifier. | 00A |
| SVFB_ReadMultiObject | Reads multiple objects of a servo amplifier. | 00A |
| SVFB_WriteMultiObject | Writes multiple objects of a servo amplifier. | 00A |

Restrictions and precautions for all FBs

Description

The following describes restrictions and precautions common to all FBs.

The restrictions and precautions specific to each FB are separately described. Refer to  Page 14 Details of the FB Library.

- The FB does not include error recovery processing. Program the error recovery processing separately in accordance with the required system operation.
- The FB does not detect an alarm or a warning that has occurred in the servo amplifier. Program the processing to monitor alarms and warnings in the servo amplifiers. For the alarms and warnings that have occurred in the servo amplifiers, refer to the instruction manual of the servo amplifiers in use.
- The FB cannot be used in an interrupt program.
- Please ensure that Execution command (i_bEN) can be turned OFF with a program. Do not use this FB in programs that are only executed once, such as a FOR-NEXT loop because Execution command (i_bEN) cannot be turned OFF in these programs.
- The number of FB steps in a program varies depending on the CPU model to be used and I/O definitions.
- A duplicated coil warning may occur during compilation. However, the warning does not generate any problems.
- When Execution command (i_bEN) is turned ON, the FB reads data of the input label. Thus, set the input label before turning ON Execution command (i_bEN).
- The FB cannot be used for multiple axes (stations) at the same time. Create a program so that the FB is executed for each axis.

3.2 Details of the FB Library

SVFB_ReadObject (Object reading)

Name

SVFB_ReadObject

Overview

| Item | Description |
|-------------------------------|--|
| Function overview | Reads the data of the specified object from the servo amplifier. |
| Symbol [Structured Ladder] | |

Labels



■Input labels (Load: Π : Always, \uparrow : Only at start)

| No. | Variable name | Name | Data type | Import | Setting range | Description |
|-----|----------------|--------------------|---------------------------|------------|---------------|--|
| (1) | i_bEN | Execution command | Bit | \uparrow | ON, OFF | The FB is executed. |
| (2) | i_stExtDevice | External device | EXTERNAL_DEVICE structure | \uparrow | — | The information of the target servo amplifier is set. |
| (3) | i_stObjectInfo | Object information | SERVO_OBJECT structure | \uparrow | — | The object information of the target servo amplifier is set. |

■Output labels

| No. | Variable name | Name | Data type | Default value | Description |
|-----|---------------|-------------------|----------------------|---------------|--|
| (4) | o_bENO | Execution status | Bit | OFF | It indicates the FB execution status. |
| (5) | o_bOK | Normal completion | Bit | OFF | It indicates the normal completion status. |
| (6) | o_bErr | Error completion | Bit | OFF | It indicates the error completion status. |
| (7) | o_uErrID | Error code | Word [unsigned] | 0 | When reading completes with an error, an error code is output. |
| (8) | o_dReadData | Read data | Double word [signed] | 0 | The read data is output. |

Function overview

| Item | Description | |
|----------------------------------|--|-----------|
| Applicable hardware and software | Applicable CPU | QnUDVCPU |
| | Applicable engineering tool | GX Works2 |
| Language | Structured Text | |
| Number of basic steps | 222 steps | |
| Function description | <p>This FB reads the object from the target servo amplifier specified in External device (i_stExtDevice). Set the object to be read in Object information (i_stObjectInfo). Data with size of four bytes or smaller can be read. When data with size exceeding four bytes is read, the first four bytes of the data is read.</p> <p>When Execution command (i_bEN) is turned ON, SLMP frames are created based on the external device information and object information, and are sent.</p> <p>When the object has been read normally, Normal completion (o_bOK) turns ON, and the data is stored in Read data (o_dData).</p> <p>When an error has occurred in the FB, Error completion (o_bErr) turns ON, and error details are stored in Error code (o_uErrId).</p> <p>For details of error codes, refer to Page 23 Troubleshooting.</p> | |
| Restrictions and precautions | Set the information in External device and Object information before executing this FB. | |
| FB operation type | Pulsed execution (multiple scan execution type) | |
| Timing chart | <p>[Normal completion]</p>  <p>[Error completion]</p>  | |

SVFB_WriteObject (Object writing)

Name

SVFB_WriteObject

Overview

| Item | Description |
|-------------------------------|---|
| Function overview | Changes the specified object data of the servo amplifier. |
| Symbol [Structured Ladder] | |

Labels



■Input labels (Load: Π : Always, \uparrow : Only at start)

| No. | Variable name | Name | Data type | Import | Setting range | Description |
|-----|----------------|--------------------|---------------------------|------------|---------------|--|
| (1) | i_bEN | Execution command | Bit | \uparrow | ON, OFF | The FB is executed. |
| (2) | i_stExtDevice | External device | EXTERNAL_DEVICE structure | \uparrow | — | The information of the target servo amplifier is set. |
| (3) | i_stObjectInfo | Object information | SERVO_OBJECT structure | \uparrow | — | The object information of the target servo amplifier is set. |

■Output labels

| No. | Variable name | Name | Data type | Default value | Description |
|-----|---------------|-------------------|-----------------|---------------|--|
| (4) | o_bENO | Execution status | Bit | OFF | It indicates the FB execution status. |
| (5) | o_bOK | Normal completion | Bit | OFF | It indicates the normal completion status. |
| (6) | o_bErr | Error completion | Bit | OFF | It indicates the error completion status. |
| (7) | o_uErrID | Error code | Word [unsigned] | 0 | When writing completes with an error, an error code is output. |

Function overview

| Item | Description |
|----------------------------------|--|
| Applicable hardware and software | Applicable CPU QnUDVCPU |
| | Applicable engineering tool GX Works2 |
| Language | Structured Text |
| Number of basic steps | 212 steps |
| Function description | <p>This FB writes the object to the target servo amplifier specified in External device (i_stExtDevice). Set the object to be written in Object information (i_stObjectInfo). Data with size of four bytes or smaller can be written. When Execution command (i_bEN) is turned ON, SLMP frames are created based on the external device information and object information, and are sent.</p> <p>When the object has been written normally, Normal completion (o_bOK) turns ON.</p> <p>When an error has occurred in the FB, Error completion (o_bErr) turns ON, and error details are stored in Error code (o_uErrID).</p> <p>For details of error codes, refer to  Page 23 Troubleshooting.</p> |
| Restrictions and precautions | Set the information in External device and Object information before executing this FB. |
| FB operation type | Pulsed execution (multiple scan execution type) |
| Timing chart | <p>[Normal completion]</p>  <p>[Error completion]</p>  |

SVFB_ReadMultiObject (Reading multiple objects)

Name

SVFB_ReadMultiObject

Overview

| Item | Description |
|-------------------------------|--|
| Function overview | Reads multiple object data from the servo amplifier. |
| Symbol [Structured Ladder] | |

Labels

■Input labels (Load: Π : Always, \uparrow : Only at start)

| No. | Variable name | Name | Data type | Import | Setting range | Description |
|-----|----------------|--------------|--------------------------------|--------|---------------|--|
| (1) | io_stObjectTbl | Object table | SERVO_OBJECT structure (0..33) | Π | — | The object to be read is set in the index number and sub index number. In addition, the read data is stored. |



■Input labels (Load: Π : Always, \uparrow : Only at start)

| No. | Variable name | Name | Data type | Import | Setting range | Description |
|-----|---------------|-------------------|---------------------------|------------|---------------|---|
| (2) | i_bEN | Execution command | Bit | \uparrow | ON, OFF | The FB is executed. |
| (3) | i_stExtDevice | External device | EXTERNAL_DEVICE structure | Π | — | The information of the target servo amplifier is set. |
| (4) | i_wNum | Number registered | Word [unsigned] | \uparrow | 1 to 34 | The value set in the object information table is specified. |

■Output labels

| No. | Variable name | Name | Data type | Default value | Description |
|-----|---------------|-------------------|-----------------|---------------|--|
| (5) | o_bENO | Execution status | Bit | OFF | It indicates the FB execution status. |
| (6) | o_bOK | Normal completion | Bit | OFF | It indicates the normal completion status. |
| (7) | o_bBusy | Busy | Bit | OFF | It indicates that the FB is in execution. |
| (8) | o_bErr | Error completion | Bit | OFF | It indicates the error completion status. |
| (9) | o_uErrID | Error code | Word [unsigned] | 0 | When reading completes with an error, an error code is output. |

Function overview

| Item | Description | |
|----------------------------------|--|-----------|
| Applicable hardware and software | Applicable CPU | QnUDVCPU |
| | Applicable engineering tool | GX Works2 |
| Language | Structured Text | |
| Number of basic steps | 431 steps | |
| Function description | <p>This FB reads multiple objects by using Object reading (SVFB_ReadObject) of the servo amplifier.</p> <p>The FB reads the objects set in Object table (io_stObjectTbl) from the target servo amplifier specified in External device (i_stExtDevice). The objects specified by Number registered (i_wNum) are read in order from the beginning. Up to 34 objects can be read.</p> <p>When Execution command (i_bEN) is turned ON, SLMP frames are created based on the external device information and object information, and are sent.</p> <p>Busy (o_bBusy) is ON while the objects are being read.</p> <p>When the objects have been read normally, Normal completion (o_bOK) turns ON and Busy (o_bBusy) turns OFF.</p> <p>When an error has occurred in the FB, Error completion (o_bErr) turns ON and error details are stored in Error code (o_uErrId).</p> <p>Not all objects specified by Number registered (i_wNum) may be read because the FB stops the processing when an error occurs.</p> <p>For details of error codes, refer to  Page 23 Troubleshooting.</p> | |
| Restrictions and precautions | <ul style="list-style-type: none"> • This FB uses SVFB_ReadObject. Do not execute the FB of SVFB_ReadObject while this FB is in execution. • Set the information in External device and Object table before executing this FB. • This FB always refers to External device and Object table while Busy is ON. Do not change the data. | |
| FB operation type | Pulsed execution (multiple scan execution type) | |
| Timing chart | <p>[Normal completion]</p>  <p>[Error completion]</p>  | |

SVFB_WriteMultiObject (Writing multiple objects)

Name

SVFB_WriteMultiObject

Overview

| Item | Description |
|-------------------------------|--|
| Function overview | Changes multiple object data of the servo amplifier. |
| Symbol [Structured Ladder] | |

Labels



■ Input labels (Load: Π : Always, \uparrow : Only at start)

| No. | Variable name | Name | Data type | Import | Setting range | Description |
|-----|---------------|-------------------|--------------------------------|------------|---------------|--|
| (1) | i_bEN | Execution command | Bit | \uparrow | ON, OFF | The FB is executed. |
| (2) | i_stExtDevice | External device | EXTERNAL_DEVICE structure | Π | — | The information of the target servo amplifier is set. |
| (3) | i_stObjectTbl | Object table | SERVO_OBJECT structure (0..33) | Π | — | The object information of the target servo amplifier is set. |
| (4) | i_wNum | Number registered | Word [unsigned] | \uparrow | 1 to 34 | The value set in the object information table is specified. |

■ Output labels

| No. | Variable name | Name | Data type | Default value | Description |
|-----|---------------|-------------------|-----------------|---------------|--|
| (5) | o_bENO | Execution status | Bit | OFF | It indicates the FB execution status. |
| (6) | o_bOK | Normal completion | Bit | OFF | It indicates the normal completion status. |
| (7) | o_bBusy | Busy | Bit | OFF | It indicates that the FB is in execution. |
| (8) | o_bErr | Error completion | Bit | OFF | It indicates the error completion status. |
| (9) | o_uErrID | Error code | Word [unsigned] | 0 | When writing completes with an error, an error code is output. |

Function overview

| Item | Description | |
|----------------------------------|---|-----------|
| Applicable hardware and software | Applicable CPU | QnUDVCPU |
| | Applicable engineering tool | GX Works2 |
| Language | Structured Text | |
| Number of basic steps | 407 steps | |
| Function description | <p>This FB writes multiple objects by using Object writing (SVFB_WriteObject) of the servo amplifier.</p> <p>The FB writes the objects set in Object table (i_stObjectTbl) to the target servo amplifier specified in External device (i_stExtDevice). The objects specified by Number registered (i_wNum) are written in order from the beginning. Up to 34 objects can be written.</p> <p>When Execution command (i_bEN) is turned ON, SLMP frames are created based on the external device information and object information, and are sent.</p> <p>Busy (o_bBusy) is ON while the objects are being written.</p> <p>When the objects have been written normally, Normal completion (o_bOK) turns ON and Busy (o_bBusy) turns OFF.</p> <p>When an error has occurred in the FB, Error completion (o_bErr) turns ON and error details are stored in Error code (o_uErrID).</p> <p>Not all objects specified by Number registered (i_wNum) may be written because the FB stops the processing when an error occurs.</p> <p>For details of error codes, refer to  Page 23 Troubleshooting.</p> | |
| Restrictions and precautions | <ul style="list-style-type: none"> • This FB uses SVFB_WriteObject. Do not execute the FB of SVFB_WriteObject while this FB is in execution. • Set the information in External device and Object table before executing this FB. • This FB always refers to External device and Object table while Busy is ON. Do not change the data. | |
| FB operation type | Pulsed execution (multiple scan execution type) | |
| Timing chart | <p>[Normal completion]</p>  <p>[Error completion]</p>  | |

3.3 List of Structures

The following table lists the structures used in each library.

| Structure name | Description | Version |
|-----------------|-----------------------------|---------|
| EXTERNAL_DEVICE | External device information | 00A |
| SERVO_OBJECT | Object information | 00A |

Structure

EXTERNAL_DEVICE (External device information)

■Name

EXTERNAL_DEVICE

■Labels

| Label name | Data type | Access Type | Description |
|-----------------|----------------------|-------------|---|
| wIPAddress | Word [signed] (0..1) | Read/Write | Sets the IP address of the external device in hexadecimal. [0]: First and second octets [1]: Third and fourth octets Example) For the IP address: 192.168.3.1 [0]: HC0A8 [1]: H0301 |
| wPortNo | Word [signed] | Read/Write | Sets the port number of the external device. For the MR-JE-C, set 5010. |
| wResendNum | Word [signed] | Read/Write | Sets the number of resends of the SLMP frame send. If a value out of the range is set, the SLMP frame is resent for three times. [Setting range] 0 to 15 (times) |
| wMonitoringTime | Word [signed] | Read/Write | Sets the arrival monitoring time of the SLMP frame send. If a value out of the range is set, the arrival monitoring time is set as 0 (10 seconds). [Setting range] 0: 10 seconds 1 to 32767: 1 to 32767 seconds |

SERVO_OBJECT (Object information)

■Name

SERVO_OBJECT

■Labels

| Label name | Data type | Access Type | Description |
|------------|----------------------|-------------|---|
| wIndex | Word [signed] | Read/Write | Sets the index number of the servo amplifier object. |
| wSubIndex | Word [signed] | Read/Write | Sets the sub index number of the servo amplifier object. |
| wSize | Word [signed] | Read/Write | Sets the data of the object at writing. This setting is ignored at reading. [Setting range] At writing: 1 to 4 (byte) At reading: 0 |
| dData | Double word [signed] | Read/Write | Sets the data of the object at writing. This setting is ignored at reading. Example) For the data of "ABC", set H00434241. |

3.4 Troubleshooting

List of error codes

The following table lists the error codes to be output in this program.

For the errors caused by the SLMPSEND instruction, refer to the following.

 QCPU User's Manual (Hardware Design, Maintenance and Inspection)

For other errors, refer to the error codes of the module.

| Error code | Description | Remedy |
|------------|-------------------------|---|
| 100 | Data size error | A value out of the range is set as a data size of the written object. Set a value within the setting range and then execute the FB again. [Setting range] 1 to 4 |
| 101 | Registered number error | A value out of the range is set as the number of registered objects. Set a value within the setting range and then execute the FB again. [Setting range] 1 to 34 |
| 200 | SLMP error completion | The SLMPSEND instruction has completed with an error. Check the completion status of the SLMP frame send instruction or the error information of the response frame. Eliminate the error cause and then execute the FB again. |

MEMO

INSTRUCTION INDEX

S

| | |
|---------------------------------|----|
| SVFB_ReadMultiObject | 18 |
| SVFB_ReadObject | 14 |
| SVFB_WriteMultiObject | 20 |
| SVFB_WriteObject | 16 |



MEMO

REVISIONS

*The manual number is given on the bottom left of the back cover.

| Revision date | *Manual number | Description |
|---------------|------------------|---------------|
| May 2017 | BCN-B62005-828-A | First edition |

Japanese manual number: BCN-B62005-827-A

This manual confers no industrial property rights of any other kind, nor does it confer any patent licenses. Mitsubishi Electric Corporation cannot be held responsible for any problems involving industrial property rights which may occur as a result of using the contents noted in this manual.

© 2017 MITSUBISHI ELECTRIC CORPORATION

TRADEMARKS

The company names, system names and product names mentioned in this manual are either registered trademarks or trademarks of their respective companies.

In some cases, trademark symbols such as '™' or '®' are not specified in this manual.

BCN-B62005-828-A(1705)MEE

mitsubishi electric corporation

HEAD OFFICE : TOKYO BUILDING, 2-7-3 MARUNOUCHI, CHIYODA-KU, TOKYO 100-8310, JAPAN
NAGOYA WORKS : 1-14, YADA-MINAMI 5-CHOME, HIGASHI-KU, NAGOYA, JAPAN

When exported from Japan, this manual does not require application to the
Ministry of Economy, Trade and Industry for service transaction permission.

Specifications subject to change without notice.